

# O.S.K.

**ALL MADE IN JAPAN.**



## **ENGINE TIMING COMPONENTS**

- **TIMING KIT**
- **TIMING SET**
- **CHAIN TENSIONER**
- **CHAIN GUIDE**
- **GEAR**



OSAKA  
OKAYAMA



ISO 9001  
JIS Q 9001











JAB  
CM004









**2020 – No. 1**

[www.timingkit.jp](http://www.timingkit.jp)





## NEW TIMING KIT LIST

KIT NO.	ENGINE	PHOTO	APPLICATION
<b>TOYOTA</b>			
<b>T056K</b>	1ZR-FE 2ZR-FE <i>Without</i> Pump Drive		1ZR-FE ZRE120,141,151,171,181,ZSP91 etc. 2ZR-FE ZRE142,144,152,154,172,ZSP90 etc.
<b>T057K</b>	1ZR-FE 2ZR-FE <i>With</i> Pump Drive		1ZR-FE ZRE120,141,151,171,181,ZSP91 etc. 2ZR-FE ZRE142,144,152,154,172,ZSP90 etc.
<b>T058K</b>	2ZR-FXE <i>HYBRID</i> <i>Without</i> Pump Drive		2ZR-FXE ZVW30,35,40,41,50,51,52,55,ZWR80 ZWE150,186,ZWA10,ZYX10
<b>T059K</b>	2ZR-FXE <i>HYBRID</i> <i>With</i> Pump Drive		2ZR-FXE ZVW30,35,40,41,50,51,52,55,ZWR80 ZWE150,186,ZWA10,ZYX10
<b>T060K</b>	1ZR-FAE 2ZR-FAE <i>Without</i> Pump Drive		1ZR-FAE ZRE151,181,185,ZGR20,ZRT270 2ZR-FAE ZRE142,144,152,154,ZGE20,25 etc.
<b>T061K</b>	1ZR-FAE 2ZR-FAE <i>With</i> Pump Drive		1ZR-FAE ZRE151,181,185,ZGR20,ZRT270 2ZR-FAE ZRE142,144,152,154,ZGE20,25 etc.
<b>T062K</b>	3ZR-FE <i>Without</i> Pump Drive		3ZR-FE ZRE143,153,173,ZRT272 ZSA42,44,ZGE21,ZRR70,75,ZGR22
<b>T063K</b>	3ZR-FE <i>With</i> Pump Drive		3ZR-FE ZRE143,153,173,ZRT272 ZSA42,44,ZGE21,ZRR70,75,ZGR22

## NEW TIMING KIT LIST

KIT NO.	ENGINE	PHOTO	APPLICATION
<b>TOYOTA</b>			
<b>T064K</b>	3ZR-FAE (2004-08/2015) <i>Without</i> Pump Drive		3ZR-FAE ZRT272,ZSU60,65,ZGZ10,15,ZGE22 ZRR70,75,80,85,ZRT261,ZGX10 ZGM11
<b>T065K</b>	3ZR-FAE (2004-08/2015) <i>With</i> Pump Drive		3ZR-FAE ZRT272,ZSU60,65,ZGZ10,15,ZGE22 ZRR70,75,80,85,ZRT261,ZGX10 ZGM11
<b>T066K</b>	1KR-FE NEW (04/2014 - UP) 1KR-VET		1KR-FE (NEW) (04/2014 - UP) KSP130,KGC30,35,M700A,M710A 1KR-VET M910A
<b>NISSAN</b>			
<b>N145K</b>	QR25DE QR20DE Main Drive Only 13085-6N200 Guide		QR25DE (2001 - 01/2012) E25,T31,J31,J32,U30,U31,S35,Z50 QR20DE (2001 - 01/2012) E25,T30,C24,P12,Y11,F24
<b>N146K</b>	QR25DE QR20DE With Balancer Dr. 13070-6N215 Ten. 13085-6N200 Guide		QR25DE (2001 - 01/2012) J31,U30,U31,Z50 QR20DE (2001 - 01/2012) T30,C24,P12,Y11
<b>N147K</b>	QR25DE QR20DE With Balancer Dr. 13070-JG30A Ten. 13085-6N200 Guide		QR25DE (2007 - 01/2012) E25,T31,J32,S35 QR20DE (2007 - 01/2012) E25,F24
<b>N148K</b>	QR25DE QR20DE Main Drive Only 13085-1JB1A Guide		QR25DE (01/2012 - UP) E25,E26,T31,S35,Z51 QR20DE (01/2012 - UP) T30
<b>N149K</b>	QR25DE QR20DE With Balancer Dr. 13085-1JB1A Guide		QR25DE (01/2012 - UP) E25,E26,T31,S35,Z51 QR20DE (01/2012 - UP) T30

## TIMING KIT & SET NUMBER LIST

ENGINE MODEL	YEAR MODEL				
		"K or X" KIT WITH SEAL,GASKET	"B"KIT WITHOUT SEAL,GASKET	"TG"SET TENSIONER + GUIDES	"G"SET GUIDES
<b>TOYOTA</b>					
KC , 3KC	1974-1987	T001K	T001B	T001TG	
4K	1979-1987	T002K	T002B	T002TG	
4KEC	1982-1983	T014K	T014B	T002TG	
5K	1983-1999	T024K	T024B	T024TG	
7K	1999-2007	T025K	T025B	T025TG	
2TC , 3TC	1974-1983	T003K	T003B	T003TG	
2Y , 3YEC	1982-1985	T010K	T010B	T003TG	
4YEC	1985-2008	T015K	T015B	T003TG	
5R	1979-1985	T009K	T009B	T009TG	
18RC	1976-1983	T007K	T007B	T007TG	
20R , 21R	98L DOUBLE	T005K	T005B	T005TG	T005G
21R , 22R	98L SINGLE	T008K	T008B	T008TG	T008G
22REC , 22RTEC	96L SINGLE	T011K	T011B	T011TG	T011G
1RZ-E , 2RZ-E	1989-1993	T016K	T016B	T016TG	T016G
2RZ-FE (13523-75020 Cam Gear)	1997-2004	T018K	T018B	T018TG	T018G
1RZ-E , 2RZ-E (13523-75010 Cam Gear)	1994-2004	T052K	T052B	T018TG	T018G
3RZ-FE (Main Drive Only)	1993-2007	T019K	T019B	T019TG	T019G
3RZ-FE (With Balancer Drive)	1993-2007	T049K	T049B	T049TG	T049G
2TZ-FE	1992-1993	T017X	T017B	T016TG	T016G
2TZ-FZE	1994-1999	T053X	T053B	T018TG	T018G
1FZ-FE	1992-2009	T020K	T020B	T020TG	T020G
1ZZ-FE (30mm Tensioner )	1998-2000	T021K	T021B	T021TG	T021G
1ZZ-FE (28.5mm Tensioner)	1999-2010	T022K	T022B	T022TG	T022G
1ZZ-FE (28.5mm Tensioner) Special (2 Regular cam gears)	1999-2010	T023K	T023B	T022TG	T022G
2ZZ-GE	1999-2006	T029K	T029B	T029TG	T029G
3ZZ-FE , 4ZZ-FE	2000-UP	T026K	T026B	T026TG	T022G
3ZZ-FE , 4ZZ-FE Special (2 Regular cam gears)	2000-UP	T044K	T044B	T026TG	T022G

## TIMING KIT & SET NUMBER LIST

ENGINE MODEL	YEAR MODEL	"K or X" KIT WITH SEAL,GASKET	"B"KIT WITHOUT SEAL,GASKET	"TG"SET TENSIONER + GUIDES	"G"SET GUIDES
<b>TOYOTA</b>					
1NZ-FE , 1NZ-FXE	1997-2003	T027K	T027B	T027TG	T027G
1NZ-FE , 1NZ-FXE Special (2 Regular cam gears)	1997-2003	T032K	T032B	T027TG	T027G
1NZ-FE , 1NZ-FXE	2004-UP	T040K	T040B	T027TG	T027G
1NZ-FE , 1NZ-FXE Special (2 Regular cam gears)	2004-UP	T042K	T042B	T027TG	T027G
1NZ-FE (13506-21060 CHAIN)	2004-UP	T046K	T046B	T046TG	T046G
1NZ-FE (13506-21050 CHAIN)	10/2011-UP	T047K	T047B	T047TG	T047G
2NZ-FE	1999-2003	T028K	T028B	T027TG	T027G
2NZ-FE Special (2 Regular cam gears)	1999-2003	T033K	T033B	T027TG	T027G
2NZ-FE	2004-UP	T041K	T041B	T027TG	T027G
2NZ-FE Special (2 Regular cam gears)	2004-UP	T043K	T043B	T027TG	T027G
1AZ-FE (Without VVT Engine)	2000-UP	T030K	T030B	T030TG	T030G
2AZ-FE,1AZ-FE (VVT engine) (Main Drive Only)	2000-UP	T031K	T031B	T030TG	T031G
2AZ-FE,1AZ-FE (VVT engine) (With Oil Pump Drive)	2000-UP	T051K	T051B	/	/
1TR-FE	2004-2013	T034K	T034B	T034TG	T034G
2TR-FE (Main Drive Only)	2004-UP	T037K	T037B	T037TG	T037G
2TR-FE (With Balancer Drive)	2004-UP	T050K	T050B	/	/
1SZ-FE	1999-UP	T035K	T035B	T035TG	T035G
2SZ-FE (France Made) (Silent Chain Engine)	2002-2008	T038K	T038B	T038TG	T038G
2SZ-FE (Japan Made) (Roller Chain Engine)	2002-2008	T039K	T039B	T039TG	T039G
3SZ-VE ( - 2008 ) (13545-23020 Tensioner)	2006-2008	T036K	T036B	T036TG	T036G
3SZ-VE ( 2009 - UP ) (13545-BZ011 Tensioner)	2009-UP	T054K	T054B	T054TG	T054G
1KR-FE (OLD)	- 04/2014	T045K	T045B	T045TG	T045G
1KR-FE (NEW) , 1KR-VET	04/2014 - UP	T066K	T066B	T066TG	T066G
1ND-TV	10/2001-UP	T048K	T048B	T048TG	T048G
1GR-FE (OLD)	2001-08/2009	T055K	T055B	/	/
K3-VE , K3-DE	2000-UP	TD501K	TD501B	TD501TG	TD501G

## TIMING KIT & SET NUMBER LIST

ENGINE MODEL	YEAR MODEL	"K or X" KIT WITH SEAL,GASKET	"B"KIT WITHOUT SEAL,GASKET	"TG"SET TENSIONER + GUIDES	"G"SET GUIDES
<b>TOYOTA</b>					
1ZR-FE , 2ZR-FE (Without Pump Drive)	2006 - UP	T056K	T056B		
1ZR-FE , 2ZR-FE (With Pump Drive)	2006 - UP	T057K	T057B		
2ZR-FXE (Hybrid) (Without Pump Drive)	2006 - UP	T058K	T058B		
2ZR-FXE (Hybrid) (With Pump Drive)	2006 - UP	T059K	T059B		
1ZR-FAE , 2ZR-FAE (Without Pump Drive)	2008 - UP	T060K	T060B		
1ZR-FAE , 2ZR-FAE (With Pump Drive)	2008 - UP	T061K	T061B		
3ZR-FE (Without Pump Drive)	2006 - UP	T062K	T062B		
3ZR-FE (With Pump Drive)	2006 - UP	T063K	T063B		
3ZR-FAE (Without Pump Drive)	2008 - UP	T064K	T064B		
3ZR-FAE (With Pump Drive)	2008 - UP	T065K	T065B		

## TIMING KIT & SET NUMBER LIST

ENGINE MODEL	YEAR MODEL	"K" KIT "X" KIT "KF" KIT	"B"KIT WITHOUT SEAL,GASKET	"TG"SET TENSIONER + GUIDES	"G"SET GUIDES
<b>NISSAN</b>					
TB42S					N100G
J12,J13,J15,J16		N101K	N101B		
A12,A14,A15		N102K	N102B		
H20		N108K	N108B		
L16,L18		N103K	N103B	N103TG	N103G
L20B		N104K	N104B	N104TG	N104G
L24E,L26E		N105K	N105B	N105TG	N105G
L28,L28E		N106K	N106B	N106TG	N106G
Z16,Z18 (Double chain)		N114K	N114B	N114TG	N114G
Z16,Z16S (Single chain)		N120K	N120B	N120TG	N120G
Z20,Z22 (Double chain)		N107K	N107B	N107TG	N107G
Z20,Z20S (Single chain)		N121K	N121B	N121TG	N121G
Z24,Z24i (Double chain)		N109K	N109B	N109TG	N109G
Z24i (Single chain)		N110K	N110B	N109TG	N109G
NA16S		N122K	N122B	N122TG	N122G
NA20S		N123K	N123B	N123TG	N123G
KA24E (12Valve)		N115K	N115B	N115TG	N115G
KA24DE (Upper Double Chain)		N124X	N124B	N124TG	N124G
KA24DE (Without Idler Gear) (Upper Single Chain)		N125X	N125B	N125TG	N125G
KA24DE (With Idler Gear) (Upper Single Chain)		N125KF	N125BF		



## TIMING KIT & SET NUMBER LIST

<b>ENGINE MODEL</b>	<b>YEAR MODEL</b>	<b>"K" KIT "X" KIT "KF" KIT</b>	<b>"B"KIT WITHOUT SEAL,GASKET</b>	<b>"TG"SET TENSIONER + GUIDES</b>	<b>"G"SET GUIDES</b>
<b>NISSAN</b>					
GA16i , GA15DS (12valve)		N111K	N111B	N111TG	N111G
GA16DE (Without Idler Gear)	1989-1993	N116X	N116B	N116TG	N116G
GA16DE (With Idler Gear)	1989-1993	N116KF	N116BF	N116TG	N116G
GA14DE , GA13DE (Without Idler Gear)	1989-1993	N117X	N117B	N116TG	N116G
GA14DE , GA13DE (With Idler Gear)	1989-1993	N117KF	N117BF	N116TG	N116G
GA16DE (Without Idler Gear)	1994-UP	N118X	N118B	N118TG	N118G
GA16DE (With Idler Gear)	1994-UP	N118KF	N118BF	N118TG	N118G
GA14DE , GA13DE GA16DNE (Mexico made) (Without Idler Gear)	1994-UP	N119X	N119B	N118TG	N118G
GA14DE , GA13DE GA16DNE (Mexico made) (With Idler Gear)	1994-UP	N119KF	N119BF	N118TG	N118G
CG10DE , CG13DE (Without Idler Gear)		N126X	N126B	N126TG	N126G
CG10DE , CG13DE (With Idler Gear)		N126KF	N126BF	/	/
CR10DE	2002 - 2004	N134K	N134B	N134TG	N127G
CR12DE, CR14DE (Japan Made)		N127K	N127B	N127TG	N127G
CR12DE, CR14DE (Europe, U.K. Made)		N128K	N128B	/	/
QG18DE (B15X) (USA,Mexico)		N130K	N130B	N130TG	N130G
QG18DE (B15X) (Special 2 Regular Cam Gears)		N131K	N131B	N130TG	N130G
QG18DE , QG15DE (With VVT engine)		N132K	N132B	N132TG	N132G
QG15DE , QG13DE (Without VVT Engine)		N133K	N133B	N132TG	N132G



## TIMING KIT & SET NUMBER LIST

ENGINE MODEL	YEAR MODEL	"K" KIT "X" KIT "KF" KIT	"B"KIT WITHOUT SEAL,GASKET	"TG"SET TENSIONER + GUIDES	"G"SET GUIDES
<b>NISSAN</b>					
HR16DE , HR15DE	- 01/2010	N136K	N136B		
HR16DE , HR15DE	01/2010 - UP	N137K	N137B		
HR15DE with CVT	- 12/2009	N138K	N138B		
HR15DE with CVT	01/2010 - UP	N139K	N139B		
HR16DE HR15DE (Dual VVT Engine)	06/2010 - UP	N140K	N140B		
HR16DE (MICRA Mexico Made)	02/2011 - UP	N141K	N141B		
HR16DE (VERSA Mexico Made)	06/2011 - UP	N142K	N142B		
HR12DE	02/2010 - UP	N143K	N143B		
HR12DDR (Dual VVT Engine)	09/2012 - UP	N144K	N144B		
QR25DE QR20DE (Main Drive Only)	2001-01/2012	N145K	N145B		
QR25DE QR20DE (With Balancer Drive) (13070-6N215)	2001-01/2012	N146K	N146B		
QR25DE QR20DE (With Balancer Drive) (13070-JG30A)	2007-01/2012	N147K	N147B		
QR25DE QR20DE (Main Drive Only)	01/2012 - UP	N148K	N148B		
QR25DE QR20DE (With Balancer Drive) (13070-JG30A)	01/2012 - UP	N149K	N149B		
ZD30DDTi , ZD30DD (13070-2W200 Tensioner)	2004-09/2007	N129X	N129B	N129TG	N129G
ZD30DDTi , ZD30DD (13070-MA70A Tensioner)	09/2007 - UP	N135X	N135B	N135TG	N135G

## TIMING KIT & SET NUMBER LIST

<b>ENGINE MODEL</b>	<b>YEAR MODEL</b>	<b>"K" KIT "X" KIT "KF" KIT</b>	<b>"B"KIT WITHOUT SEAL,GASKET</b>	<b>"TG"SET TENSIONER + GUIDES</b>	<b>"G"SET GUIDES</b>
<b>MAZDA</b>					
<b>B1600NA ( 74-77 )</b>	<b>1974-1977</b>	<b>M203K</b>	<b>M203B</b>	<b>M203TG</b>	<b>M203G</b>
<b>B1800VC</b>		<b>M205K</b>	<b>M205B</b>	<b>M205TG</b>	<b>M205G</b>
<b>E3</b>		<b>M204K</b>	<b>M204B</b>	<b>M204TG</b>	<b>M204G</b>
<b>E5</b>		<b>M208K</b>	<b>M208B</b>	<b>M204TG</b>	<b>M204G</b>
<b>VB</b>		<b>M209K</b>	<b>M209B</b>	<b>M205TG</b>	<b>M205G</b>
<b>MB ( 79-80 )</b>	<b>1979-1980</b>	<b>M211K</b>	<b>M211B</b>	<b>M206TG</b>	<b>M205G</b>
<b>MB ( 80-82 )</b>	<b>1980-1982</b>	<b>M212K</b>	<b>M212B</b>	<b>M212TG</b>	<b>M212G</b>
<b>MA ( 79-80 )</b>	<b>1979-1980</b>	<b>M206K</b>	<b>M206B</b>	<b>M206TG</b>	<b>M205G</b>
<b>MA ( 82-84 )</b>	<b>1982-1984</b>	<b>M213K</b>	<b>M213B</b>	<b>M212TG</b>	<b>M212G</b>
<b>MA (Without Pump Gears)</b>		<b>M217K</b>	<b>M217B</b>	<b>M212TG</b>	<b>M212G</b>
<b>TC (With Pump Drive)</b>		<b>M214K</b>	<b>M214B</b>	/	/
<b>TC (Without Pump Drive)</b>		<b>M216K</b>	<b>M216B</b>	/	/
<b>G6 (Main Drive Only)</b>		<b>M218K</b>	<b>M218B</b>	<b>M218TG</b>	<b>M218G</b>
<b>G6 (With Balancer Drive)</b>		<b>M219K</b>	<b>M219B</b>	<b>M219TG</b>	<b>M219G</b>
<b>ZJ-VE , ZY-VE (Without VVT Gear)</b>	<b>2004-UP</b>	<b>M220K</b>	<b>M220B</b>	<b>M220TG</b>	<b>M220G</b>
<b>ZJ-VE , ZY-VE (Without VVT, 2 Regular Cam Gears)</b>	<b>2004-UP</b>	<b>M221K</b>	<b>M221B</b>	<b>M220TG</b>	<b>M220G</b>

## TIMING KIT & SET NUMBER LIST

ENGINE MODEL	YEAR MODEL	"K" KIT "X" KIT "KF" KIT	"B"KIT WITHOUT SEAL,GASKET	"TG"SET TENSIONER + GUIDES	"G"SET GUIDES
<b>MITSUBISHI</b>					
4G32		MI301K	MI301B	MI301TG	MI301G
4G52, G52B		MI302K	MI302B	MI302TG	MI302G
G54B (Balancer only)		/	MI303B	/	MI303G
4G54 , G54B (With Balancer Drive)		MI304K	MI304B	MI304TG	MI304G
G52B, G54B (Without Balancer Drive)		MI305K	MI305B	MI305TG	MI305G
4M40 (98L Double Chain) (Without Crank Gears)		MI306X	MI306B	MI306TG	MI306G
4M40 (98L Single Chain) (Without Crank Gears)		MI307X	MI307B	MI306TG	MI306G
4M41-T (With 3 Guides) (Without Crank Gears)	1999-2009	MI308X	MI308B	MI308TG	MI308G
4M41-T (With 4 Guides) (Without Crank Gears)	1999-2009	MI309X	MI309B	MI309TG	MI309G
<b>ISUZU</b>					
G161Z		I401K	I401B	I401TG	I401G
G180Z		I402K	I402B	I401TG	I401G
G200Z		I403K	I403B	I403TG	I403G
4JJ1-TCN	2004-08/2009	I404X	I404B	I404TG	I404G
<b>DAIHATSU</b>					
K3-VE, K3-DE	2000-UP	TD501K	TD501B	TD501TG	TD501G
<b>SUZUKI</b>					
J20A,J18A (Without Idler Gear)	1996-2009	S601K	S601B	S601TG	S601G
J20A,J18A (With Idler Gear)	1996-2009	S601KF	S601BF	/	/

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>T001K</b>	<b>KC</b> (1100cc)	13506-22010	CHAIN	<b>56D</b>	<b>06B</b>	<b>T001B</b>	<b>KC</b>	13506-22010	CHAIN	<b>56D</b>	<b>06B</b>
		13540-22012	TENSIONER					13540-22012	TENSIONER		
		13561-22010	GUIDE					13561-22010	GUIDE		
		13521-22010	GEAR (CRANK)					13521-22010	GEAR (CRANK)		
	<b>3KC</b> (1200cc)	13523-22010	GEAR (CAM)				<b>3KC</b>	13523-22010	GEAR (CAM)		
		90311-38024	OIL SEAL								
		11312-22010	GASKET								
		11328-22010	GASKET								
<b>T002K</b>	<b>4KC</b> (1300cc)	13506-13020	CHAIN	<b>56S</b>	<b>06B</b>	<b>T002B</b>	<b>4KC</b>	13506-13020	CHAIN	<b>56S</b>	<b>06B</b>
		13540-13010	TENSIONER					13540-13010	TENSIONER		
		13561-13020	GUIDE					13561-13020	GUIDE		
		13521-13020	GEAR (CRANK)					13521-13020	GEAR (CRANK)		
		13523-13030	GEAR (CAM)					13523-13030	GEAR (CAM)		
		90311-38024	OIL SEAL								
	11328-13011	GASKET									
	11312-13011	GASKET									
<b>T003K</b>	<b>2TC</b> (1600cc)	13506-25010	CHAIN	<b>60D</b>	<b>06B</b>	<b>T003B</b>	<b>2TC</b>	13506-25010	CHAIN	<b>60D</b>	<b>06B</b>
		13540-25010	TENSIONER					13540-25010	TENSIONER		
		13561-25010	GUIDE					13561-25010	GUIDE		
		13521-33010	GEAR (CRANK)					13521-33010	GEAR (CRANK)		
	<b>3TC</b> (1800cc)	13522-33010	GEAR (CAM)				<b>3TC</b>	13522-33010	GEAR (CAM)		
		90311-38111	OIL SEAL								
		11328-25010	GASKET								
<b>T005K</b>	<b>20R</b> (2200cc)	13506-38010	CHAIN	<b>98D</b>	<b>06B</b>	<b>T005B</b>	<b>20R</b>	13506-38010	CHAIN	<b>98D</b>	<b>06B</b>
		13540-38012	TENSIONER					13540-38012	TENSIONER		
		13561-38010	GUIDE					13561-38010	GUIDE		
		13562-38010	GUIDE					13562-38010	GUIDE		
	<b>21R</b> (2000cc)	13521-38010	GEAR (CRANK)				<b>21R</b>	13521-38010	GEAR (CRANK)		
		13523-38011	GEAR (CAM)					13523-38011	GEAR (CAM)		
		90311-45069	OIL SEAL								
		11328-38020	GASKET								
11338-38030	GASKET										
<b>T007K</b>	<b>18RU</b> (2000cc)	13506-33010	CHAIN (2pcs)	<b>62D</b>	<b>06B</b>	<b>T007B</b>	<b>18RU</b>	13506-33010	CHAIN (2pcs)	<b>62D</b>	<b>06B</b>
		13540-33014	TENSIONER					13540-33014	TENSIONER		
		13561-34010	GUIDE					13561-34010	GUIDE		
		13562-34020	GUIDE					13562-34020	GUIDE		
		13559-34020	TENSIONER					13559-34020	TENSIONER		
		13521-33010	GEAR					13521-33010	GEAR		
		13523-33010	GEAR					13523-33010	GEAR		
		13528-33010	GEAR					13528-33010	GEAR		
		13522-33010	GEAR					13522-33010	GEAR		
		90311-45094	OIL SEAL								
		11312-33014	GASKET								
		11328-33016	GASKET								
<b>T008K</b>	<b>22R</b> (2400cc)	13506-35010	CHAIN	<b>98S</b>	<b>06B</b>	<b>T008B</b>	<b>22R</b>	13506-35010	CHAIN	<b>98S</b>	<b>06B</b>
		13540-35011	TENSIONER					13540-35011	TENSIONER		
		13561-35010	GUIDE					13561-35010	GUIDE		
		13562-35010	GUIDE					13562-35010	GUIDE		
		13521-35010	GEAR (CRANK)					13521-35010	GEAR (CRANK)		
		13523-35010	GEAR (CAM)					13523-35010	GEAR (CAM)		
		90311-45002	OIL SEAL								
		11328-35010	GASKET								
11329-35010	GASKET										
<b>T009K</b>	<b>5R</b> (2000cc)	13506-44010	CHAIN	<b>52D</b>	<b>06B</b>	<b>T009B</b>	<b>5R</b>	13506-44010	CHAIN	<b>52D</b>	<b>06B</b>
		13540-44010	TENSIONER					13540-44010	TENSIONER		
		13561-44010	GUIDE					13561-44010	GUIDE		
		13521-33010	GEAR (CRANK)					13521-33010	GEAR (CRANK)		
		13522-33010	GEAR (CAM)					13522-33010	GEAR (CAM)		
		90311-38024	OIL SEAL								
		11312-44011	GASKET								
		11328-44010	GASKET								

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>T010K</b>	<b>1Y</b> <b>2Y</b> <b>3YEC</b> (2000cc)	13506-25010	CHAIN	<b>60D</b>	<b>06B</b>	<b>T010B</b>	<b>1Y</b> <b>2Y</b> <b>3YEC</b>	13506-25010	CHAIN	<b>60D</b>	<b>06B</b>
		13540-25010	TENSIONER					13540-25010	TENSIONER		
		13561-25010	GUIDE					13561-25010	GUIDE		
		13521-33010	GEAR (CRANK)					13521-33010	GEAR (CRANK)		
		13522-33010	GEAR (CAM)					13522-33010	GEAR (CAM)		
		90311-42007	OIL SEAL								
		11328-71010	GASKET								
		11329-71010	GASKET								
<b>T011K</b>	<b>22REC</b> (2400cc) <b>22RTEC</b> (2400cc)	13506-35030	CHAIN	<b>96S</b>	<b>06B</b>	<b>T011B</b>	<b>22REC</b> <b>22RTEC</b>	13506-35030	CHAIN	<b>96S</b>	<b>06B</b>
		13540-35011	TENSIONER					13540-35011	TENSIONER		
		13561-35020	GUIDE					13561-35020	GUIDE		
		13562-35020	GUIDE					13562-35020	GUIDE		
		13521-35010	GEAR (CRANK)					13521-35010	GEAR (CRANK)		
		13523-35020	GEAR (CAM)					13523-35020	GEAR (CAM)		
		90311-45002	OIL SEAL								
		11328-35020	GASKET								
11329-35020	GASKET										
<b>T014K</b>	<b>4KEC</b> (1300cc)	13506-13020	CHAIN	<b>56S</b>	<b>06B</b>	<b>T014B</b>	<b>4KEC</b>	13506-13020	CHAIN	<b>56S</b>	<b>06B</b>
		13540-13010	TENSIONER					13540-13010	TENSIONER		
		13561-13020	GUIDE					13561-13020	GUIDE		
		13521-13040	GEAR (CRANK)					13521-13040	GEAR (CRANK)		
		13523-13030	GEAR (CAM)					13523-13030	GEAR (CAM)		
		90311-38022	OIL SEAL								
		11328-13011	GASKET								
		11312-13011	GASKET								
<b>T015K</b>	<b>4YEC</b> (2200cc)	13506-73010	CHAIN	<b>60D</b>	<b>06B</b>	<b>T015B</b>	<b>3YEC</b> <b>4YEC</b>	13506-73010	CHAIN	<b>60D</b>	<b>06B</b>
		13540-25010	TENSIONER					13540-25010	TENSIONER		
		13561-25010	GUIDE					13561-25010	GUIDE		
		13521-33010	GEAR (CRANK)					13521-33010	GEAR (CRANK)		
		13522-33010	GEAR (CAM)					13522-33010	GEAR (CAM)		
		90311-42007	OIL SEAL								
		11328-71010	GASKET								
		11329-71010	GASKET								
<b>T016K</b>	<b>1RZ-E</b> (2000cc) <b>2RZ-E</b> (2400cc)	13506-75010	CHAIN	<b>102S</b>	<b>06E</b>	<b>T016B</b>	<b>1RZ-E</b> <b>2RZ-E</b>	13506-75010	CHAIN	<b>102S</b>	<b>06E</b>
		13540-75010	TENSIONER					13540-75010	TENSIONER		
		13552-75010	TEN. GASKET					13552-75010	TEN. GASKET		
		13559-75011	GUIDE					13559-75011	GUIDE		
		13561-76010	GUIDE					13561-76010	GUIDE		
		13521-75010	GEAR (CRANK)					13521-75010	GEAR (CRANK)		
		13523-75010	GEAR (CAM)					13523-75010	GEAR (CAM)		
		90311-48014	OIL SEAL								
		11328-75010	GASKET								
11329-75010	GASKET										
<b>T017X</b>	<b>2TZ-FE</b> (2400cc)	13506-75010	CHAIN	<b>102S</b>	<b>06E</b>	<b>T017B</b>	<b>2TZ-FE</b>	13506-75010	CHAIN	<b>102S</b>	<b>06E</b>
		13540-75010	TENSIONER					13540-75010	TENSIONER		
		13552-75010	TEN. GASKET					13552-75010	TEN. GASKET		
		13559-75011	GUIDE					13559-75011	GUIDE		
		13561-76010	GUIDE					13561-76010	GUIDE		
		13523-75010	GEAR (CAM)					13523-75010	GEAR (CAM)		
		90311-48014	OIL SEAL								
		11328-75010	GASKET								
11329-75010	GASKET										
<b>T018K</b>	<b>2RZ-FE</b> (2400cc) <b>13523-75020 GEAR</b>	13506-75010	CHAIN	<b>102S</b>	<b>06E</b>	<b>T018B</b>	<b>2RZ-FE</b> <b>13523-75020 GEAR</b>	13506-75010	CHAIN	<b>102S</b>	<b>06E</b>
		13540-75020	TENSIONER					13540-75020	TENSIONER		
		13552-75010	TEN. GASKET					13552-75010	TEN. GASKET		
		13559-76010	GUIDE					13559-76010	GUIDE		
		13561-76020	GUIDE					13561-76020	GUIDE		
		13521-75010	GEAR (CRANK)					13521-75010	GEAR (CRANK)		
		13523-75020	GEAR (CAM)					13523-75020	GEAR (CAM)		
		90311-48014	OIL SEAL								
		11328-75010	GASKET								
11329-75010	GASKET										

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>T019K</b>	<b>3RZ-FE</b> (2700cc)  <b>Without Balancer Drive</b>	13506-75020	CHAIN	106S	06E	<b>T019B</b>	<b>3RZ-FE</b>  <b>Without Balancer Drive</b>	13506-75020	CHAIN	106S	06E
		13540-75020	TENSIONER					13540-75020	TENSIONER		
		13552-75010	TEN. GASKET					13552-75010	TEN. GASKET		
		13559-75020	GUIDE					13559-75020	GUIDE		
		13561-75020	GUIDE					13561-75020	GUIDE		
		13521-75010	GEAR (CRANK)					13521-75010	GEAR (CRANK)		
		13523-75010	GEAR (CAM)					13523-75010	GEAR (CAM)		
		90311-48014	OIL SEAL								
		11328-75020	GASKET								
11329-75020	GASKET										
<b>T020K</b>	<b>1FZ-FE</b> (4500cc)	13506-66010	CHAIN	112S	06E	<b>T020B</b>	<b>1FZ-FE</b>	13506-66010	CHAIN	112S	06E
		13540-66011	TENSIONER					13540-66011	TENSIONER		
		13552-66010	TEN. GASKET					13552-66010	TEN. GASKET		
		13559-66011	GUIDE					13559-66011	GUIDE		
		13561-66010	GUIDE					13561-66010	GUIDE		
		13521-66020	GEAR (CRANK)					13521-66020	GEAR (CRANK)		
		13523-66020	GEAR (CAM)					13523-66020	GEAR (CAM)		
		90311-52013	OIL SEAL								
		11328-66020	GASKET								
<b>T021K</b>	<b>1ZZ-FE</b> (1800cc)  <b>Without VVT Engine</b>	13506-22030	CHAIN	130S	05E	<b>T021B</b>	<b>1ZZ-FE</b>  <b>Without VVT Engine</b>	13506-22030	CHAIN	130S	05E
		13540-22020	TENSIONER		30mm			13540-22020	TENSIONER		30mm
		13559-22010	GUIDE					13559-22010	GUIDE		
		13561-22020	GUIDE					13561-22020	GUIDE		
		13521-22020	GEAR (CRANK)					13521-22020	GEAR (CRANK)		
		13523-22020	GEAR (CAM)	2pcs				13523-22020	GEAR (CAM)	2pcs	
		90311-38059	OIL SEAL								
<b>T022K</b>	<b>1ZZ-FE</b> (1800cc)  <b>With VVT Engine</b>	13506-22030	CHAIN	130S	05E	<b>T022B</b>	<b>1ZZ-FE</b>  <b>With VVT Engine</b>	13506-22030	CHAIN	130S	05E
		13540-22022	TENSIONER		28.5mm			13540-22022	TENSIONER		28.5mm
		13559-22011	GUIDE					13559-22011	GUIDE		
		13561-22020	GUIDE					13561-22020	GUIDE		
		13521-22020	GEAR (CRANK)					13521-22020	GEAR (CRANK)		
		13523-22020	GEAR (CAM)	1pc				13523-22020	GEAR (CAM)	1pc	
90311-38059	OIL SEAL										
<b>T023K</b>	<b>1ZZ-FE</b> (1800cc)  <b>Special 2 Cam Gears</b>	13506-22030	CHAIN	130S	05E	<b>T023B</b>	<b>1ZZ-FE</b>  <b>Special 2 Cam Gears</b>	13506-22030	CHAIN	130S	05E
		13540-22022	TENSIONER		28.5mm			13540-22022	TENSIONER		28.5mm
		13559-22011	GUIDE					13559-22011	GUIDE		
		13561-22020	GUIDE					13561-22020	GUIDE		
		13521-22020	GEAR (CRANK)					13521-22020	GEAR (CRANK)		
		13523-22020	GEAR (CAM)	2pcs				13523-22020	GEAR (CAM)	2pcs	
90311-38059	OIL SEAL										
<b>T024K</b>	<b>5K</b> (1500cc)	13506-13040	CHAIN	56S	06E	<b>T024B</b>	<b>5K</b>	13506-13040	CHAIN	56S	06E
		13540-13011	TENSIONER					13540-13011	TENSIONER		
		13561-13020	GUIDE					13561-13020	GUIDE		
		13521-13020	GEAR (CRANK)					13521-13020	GEAR (CRANK)		
		13523-13030	GEAR (CAM)					13523-13030	GEAR (CAM)		
		90311-38086	OIL SEAL								
		11312-13011	GASKET								
		11328-13030	GASKET								
<b>T025K</b>	<b>7K</b> <b>7KE</b> (1800cc)	13506-13040	CHAIN	56S	06E	<b>T025B</b>	<b>7K</b>  <b>7KE</b>	13506-13040	CHAIN	56S	06E
		13540-13023	TENSIONER					13540-13023	TENSIONER		
		13561-13020	GUIDE					13561-13020	GUIDE		
		13521-06010	GEAR (CRANK)					13521-06010	GEAR (CRANK)		
		13523-13030	GEAR (CAM)					13523-13030	GEAR (CAM)		
		90311-38086	OIL SEAL								
		11312-06010	GASKET								
		11328-06010	GASKET								
<b>T026K</b>	<b>3ZZ-FE</b> (1600cc)  <b>4ZZ-FE</b> (1400cc)	13506-22030	CHAIN	130S	05E	<b>T026B</b>	<b>3ZZ-FE</b>  <b>4ZZ-FE</b>	13506-22030	CHAIN	130S	05E
		13540-0D030	TENSIONER					13540-0D030	TENSIONER		
		13559-22011	GUIDE					13559-22011	GUIDE		
		13561-22020	GUIDE					13561-22020	GUIDE		
		13521-0D020	GEAR (CRANK)					13521-0D020	GEAR (CRANK)		
		13523-0D010	GEAR (CAM)	1pc	=22020			13523-0D010	GEAR (CAM)	1pc	=22020
		90311-38059	OIL SEAL								

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>T027K</b>	<b>1NZ-FE</b> <b>1NZ-FXE</b> (1500cc)	13506-21020	CHAIN	124S	05E	<b>T027B</b>	<b>1NZ-FE</b> <b>1NZ-FXE</b>	13506-21020	CHAIN	124S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
		13559-21010	GUIDE					13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-21020	GEAR (CAM)	1pc				13523-21020	GEAR (CAM)	1pc	
		90311-25021	OIL SEAL								
<b>T028K</b>	<b>2NZ-FE</b> (1300cc)	13506-21030	CHAIN	120S	05E	<b>T028B</b>	<b>2NZ-FE</b>	13506-21030	CHAIN	120S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
		13559-21010	GUIDE					13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-21020	GEAR (CAM)	1pc				13523-21020	GEAR (CAM)	1pc	
		90311-25021	OIL SEAL								
<b>T029K</b>	<b>2ZZ-GE</b> (1800cc)	13506-88600	CHAIN	136S	05E	<b>T029B</b>	<b>2ZZ-GE</b>	13506-88600	CHAIN	136S	05E
		13540-88600	TENSIONER					13540-88600	TENSIONER		
		13559-88600	GUIDE					13559-88600	GUIDE		
		13561-88600	GUIDE					13561-88600	GUIDE		
		13521-0D010	GEAR (CRANK)		=22020			13521-0D010	GEAR (CRANK)		=22020
		13523-0D010	GEAR (CAM)		=22020			13523-0D010	GEAR (CAM)		=22020
		90311-38059	OIL SEAL								
		11328-88600	GASKET								
11329-88600	GASKET										
<b>T030K</b>	<b>1AZ-FE</b> (2000cc)	13506-28011/20	CHAIN	134S	05E	<b>T030B</b>	<b>1AZ-FE</b>	13506-28011/20	CHAIN	134S	05E
		13540-28010	TENSIONER		=0H010			13540-28010	TENSIONER		=0H010
		13552-28010	GASKET					13552-28010	GASKET		
		13559-28010	GUIDE		=0H010			13559-28010	GUIDE		=0H010
		13561-28010	GUIDE		=0H010			13561-28010	GUIDE		=0H010
	<b>Without VVT Engine</b>	13521-28010/30	GEAR (CRANK)				13521-28010/30	GEAR (CRANK)			
		13523-28030	GEAR (CAM)				13523-28030	GEAR (CAM)			
		13523-22020	GEAR (CAM)				13523-22020	GEAR (CAM)			
		90311-38078	OIL SEAL								
<b>T031K</b>	<b>2AZ-FE</b> (2400cc)	13506-28011/20	CHAIN	134S	05E	<b>T031B</b>	<b>2AZ-FE</b>	13506-28011/20	CHAIN	134S	05E
		13540-28010	TENSIONER		=0H010			13540-28010	TENSIONER		=0H010
	<b>1AZ-FE</b> (2000cc)	13552-28010	GASKET				<b>1AZ-FE</b>	13552-28010	GASKET		
		13559-28010	GUIDE		=0H010			13559-28010	GUIDE		=0H010
	<b>With VVT Engine</b>	13561-28010	GUIDE		=0H010		<b>With VVT Engine</b>	13561-28010	GUIDE		=0H010
		13521-28010/30	GEAR (CRANK)					13521-28010/30	GEAR (CRANK)		
		13523-22020	GEAR (CAM)					13523-22020	GEAR (CAM)		
		90311-38078	OIL SEAL								
<b>T032K</b>	<b>1NZ-FE</b> <b>1NZ-FXE</b> <b>Special 2 Cam Gears</b>	13506-21020	CHAIN	124S	05E	<b>T032B</b>	<b>1NZ-FE</b> <b>1NZ-FXE</b> <b>Special 2 Cam Gears</b>	13506-21020	CHAIN	124S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
		13559-21010	GUIDE					13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-21020	GEAR (CAM)	2pcs				13523-21020	GEAR (CAM)	2pcs	
		90311-25021	OIL SEAL								
<b>T033K</b>	<b>2NZ-FE</b> <b>Special 2 Cam Gears</b>	13506-21030	CHAIN	120S	05E	<b>T033B</b>	<b>2NZ-FE</b> <b>Special 2 Cam Gears</b>	13506-21030	CHAIN	120S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
		13559-21010	GUIDE					13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-21020	GEAR (CAM)	2pcs				13523-21020	GEAR (CAM)	2pcs	
		90311-25021	OIL SEAL								
<b>T034K</b>	<b>1TR-FE</b> (2000cc)	13506-75040	CHAIN	120S	06E	<b>T034B</b>	<b>1TR-FE</b>	13506-75040	CHAIN	120S	06E
		13540-75030	TENSIONER					13540-75030	TENSIONER		
		13552-75020	GASKET					13552-75020	GASKET		
		13559-75030	GUIDE		=0C010			13559-75030	GUIDE		=0C010
		13561-75030	GUIDE		=0C010			13561-75030	GUIDE		=0C010
		13566-75010	GUIDE					13566-75010	GUIDE		
		13521-75020	GEAR (CRANK)					13521-75020	GEAR (CRANK)		
		13523-75030	GEAR (CAM)					13523-75030	GEAR (CAM)		
		90311-48020	OIL SEAL								



**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
T035K	1SZ-FE (1000cc)	13506-23010	CHAIN	148	Silent	T035B	1SZ-FE	13506-23010	CHAIN	148	Silent
		13545-23010	TENSIONER		=0J010			13545-23010	TENSIONER		=0J010
		13566-23010/1	GUIDE		=0J010			13566-23010/1	GUIDE		=0J010
		13591-23010	GUIDE		=0J010			13591-23010	GUIDE		=0J010
		13521-23010	GEAR (CRANK)					13521-23010	GEAR (CRANK)		
		13523-23050 90311-35040	GEAR (CAM) OIL SEAL		=0J010			13523-23050 90311-35040	GEAR (CAM) OIL SEAL		=0J010
T036K	3SZ-VE (1500cc)  (- 2008)	13506-B1010	CHAIN	132S	05E	T036B	3SZ-VE  (- 2008)	13506-B1010	CHAIN	132S	05E
		13545-23020	TENSIONER					13545-23020	TENSIONER		
		13566-B1020	GUIDE					13566-B1020	GUIDE		
		13591-B1020	GUIDE					13591-B1020	GUIDE		
		13562-B1010	GUIDE					13562-B1010	GUIDE		
		13521-23030	GEAR (CRANK)					13521-23030	GEAR (CRANK)		
		13523-B1010 90311-35040	GEAR (CAM) OIL SEAL					13523-B1010 90311-35040	GEAR (CAM) OIL SEAL		
T037K	2TR-FE (2700cc)	13506-75050	CHAIN	124S	06E	T037B	2TR-FE	13506-75050	CHAIN	124S	06E
		13540-75030	TENSIONER					13540-75030	TENSIONER		
		13552-75020	GASKET					13552-75020	GASKET		
		13559-75040	GUIDE		=0C020			13559-75040	GUIDE		=0C020
	Main Drive Only	13561-75040	GUIDE		=0C020		Main Drive Only	13561-75040	GUIDE		=0C020
		13566-75010	GUIDE					13566-75010	GUIDE		
		13521-75020	GEAR (CRANK)					13521-75020	GEAR (CRANK)		
		13523-75030 90311-48020	GEAR (CAM) OIL SEAL					13523-75030 90311-48020	GEAR (CAM) OIL SEAL		
T038K	2SZ-FE (1300cc)	13506-23020	CHAIN	158	Silent	T038B	2SZ-FE	13506-23020	CHAIN	158	Silent
		13545-23010	TENSIONER		=0J010			13545-23010	TENSIONER		=0J010
		13566-23020	GUIDE					13566-23020	GUIDE		
	France Made	13591-23020	GUIDE				France Made	13591-23020	GUIDE		
		13521-23020	GEAR (CRANK)					13521-23020	GEAR (CRANK)		
		13523-23050 90311-35040	GEAR (CAM) OIL SEAL		=0J010			13523-23050 90311-35040	GEAR (CAM) OIL SEAL		=0J010
T039K	2SZ-FE (1300cc)	13506-23030	CHAIN	128S	05E	T039B	2SZ-FE	13506-23030	CHAIN	128S	05E
		13545-23020	TENSIONER					13545-23020	TENSIONER		
		13566-23030	GUIDE					13566-23030	GUIDE		
		13591-23030	GUIDE					13591-23030	GUIDE		
	Japan Made	13562-23010	GUIDE				Japan Made	13562-23010	GUIDE		
		13521-23030	GEAR (CRANK)					13521-23030	GEAR (CRANK)		
		13523-23040 90311-35040	GEAR (CAM) OIL SEAL					13523-23040 90311-35040	GEAR (CAM) OIL SEAL		
T040K	1NZ-FE	13506-21020	CHAIN	124S	05E	T040B	1NZ-FE	13506-21020	CHAIN	124S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
	1NZ-FXE (2004 - )	13559-21010	GUIDE				1NZ-FXE (2004 - )	13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-22020 90311-25021	GEAR (CAM) OIL SEAL					13523-22020 90311-25021	GEAR (CAM) OIL SEAL		
T041K	2NZ-FE (1300cc)	13506-21030	CHAIN	120S	05E	T041B	2NZ-FE	13506-21030	CHAIN	120S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
	(2004 - )	13559-21010	GUIDE				(2004 - )	13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-22020 90311-25021	GEAR (CAM) OIL SEAL					13523-22020 90311-25021	GEAR (CAM) OIL SEAL		
T042K	1NZ-FE	13506-21020	CHAIN	124S	05E	T042B	1NZ-FE	13506-21020	CHAIN	124S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
	1NZ-FXE (2004 - ) Special 2 Cam Gears	13559-21010	GUIDE				1NZ-FXE (2004 - ) Special 2 Cam Gears	13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-22020 90311-25021	GEAR (CAM) OIL SEAL	2pcs				13523-22020 90311-25021	GEAR (CAM) OIL SEAL	2pcs	

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>T043K</b>	<b>2NZ-FE (2004 - ) Special 2 Cam Gears</b>	13506-21030	CHAIN	120S	05E	<b>T043B</b>	<b>2NZ-FE (2004 - ) Special 2 Cam Gears</b>	13506-21030	CHAIN	120S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
		13559-21010	GUIDE					13559-21010	GUIDE		
		13561-21010	GUIDE					13561-21010	GUIDE		
		13523-22020	GEAR (CAM)	2pcs				13523-22020	GEAR (CAM)	2pcs	
		90311-25021	OIL SEAL								
<b>T044K</b>	<b>3ZZ-FE 4ZZ-FE Special 2 Cam Gears</b>	13506-22030	CHAIN	130S	05E	<b>T044B</b>	<b>3ZZ-FE 4ZZ-FE Special 2 Cam Gears</b>	13506-22030	CHAIN	130S	05E
		13540-0D030	TENSIONER					13540-0D030	TENSIONER		
		13559-22011	GUIDE					13559-22011	GUIDE		
		13561-22020	GUIDE					13561-22020	GUIDE		
		13521-0D020	GEAR					13521-0D020	GEAR		
		13523-0D010	GEAR (CAM)	2pcs	=22020			13523-0D010	GEAR (CAM)	2pcs	=22020
90311-38059	OIL SEAL										
<b>T045K</b>	<b>1KR-FE (1000cc)</b>	13506-21020	CHAIN	124S	05E	<b>T045B</b>	<b>1KR-FE</b>	13506-21020	CHAIN	124S	=0Q010
		13540-21020	TENSIONER		=0Q010			13540-21020	TENSIONER		=0Q010
		13566-40020	GUIDE		=0Q010			13566-40020	GUIDE		=0Q010
		13591-40020	GUIDE		=0Q010			13591-40020	GUIDE		=0Q010
		13521-40020	GEAR (CRANK)					13521-40020	GEAR (CRANK)		
		13523-22020	GEAR (CAM)		=0D020			13523-22020	GEAR (CAM)		=0D020
90311-38084	OIL SEAL		=38092								
<b>T046K</b>	<b>1NZ-FE (1500cc) 13506- 21060 CHAIN</b>	13506-21060	CHAIN	132S	05E	<b>T046B</b>	<b>1NZ-FE 13506- 21060 CHAIN</b>	13506-21060	CHAIN	132S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
		13559-21010	GUIDE					13559-21010	GUIDE		
		13561-21020	GUIDE					13561-21020	GUIDE		
		13562-21010	GUIDE					13562-21010	GUIDE		
		13523-22020	GEAR (CAM)					13523-22020	GEAR (CAM)		
90311-25021	OIL SEAL										
<b>T047K</b>	<b>1NZ-FE (1500cc) 13506- 21050 CHAIN</b>	13506-21050	CHAIN	124S	05E	<b>T047B</b>	<b>1NZ-FE 13506- 21050 CHAIN</b>	13506-21050	CHAIN	124S	05E
		13540-21020	TENSIONER					13540-21020	TENSIONER		
		13559-21030	GUIDE					13559-21030	GUIDE		
		13561-21040	GUIDE					13561-21040	GUIDE		
		13523-22020	GEAR (CAM)					13523-22020	GEAR (CAM)		
90311-25021	OIL SEAL										
<b>T048K</b>	<b>1ND-TV (1400cc) Diesel Turbo</b>	13506-33020	CHAIN	106S	Diesel	<b>T048B</b>	<b>1ND-TV Diesel Turbo</b>	13506-33020	CHAIN	106S	Diesel
		13540-33020	TENSIONER					13540-33020	TENSIONER		
		13559-33010	GUIDE					13559-33010	GUIDE		
		13561-33020	GUIDE					13561-33020	GUIDE		
		13521-33020	GEAR (CRANK)					13521-33020	GEAR (CRANK)		
		13523-33021	GEAR (CAM)					13523-33021	GEAR (CAM)		
90311-38084	OIL SEAL										
<b>T049K</b>	<b>3RZ-FE (2700cc)  With Balancer Drive</b>	13506-75020	CHAIN	106S	06E	<b>T049B</b>	<b>3RZ-FE  With Balancer Drive</b>	13506-75020	CHAIN	106S	06E
		13540-75020	TENSIONER					13540-75020	TENSIONER		
		13552-75010	TEN. GASKET					13552-75010	TEN. GASKET		
		13559-75020	GUIDE					13559-75020	GUIDE		
		13561-75020	GUIDE					13561-75020	GUIDE		
		13521-75010	GEAR (CRANK)					13521-75010	GEAR		
		13523-75010	GEAR (CAM)					13523-75010	GEAR		
		13507-75010/30	CHAIN	82S	05E			13507-75010/30	CHAIN	82S	05E
		13550-75010	TENSIONER					13550-75010	TENSIONER		
		13554-75010	GUIDE					13554-75010	GUIDE		
	13562-75010	GUIDE			13562-75010		GUIDE				
	13563-75010	GUIDE			13563-75010		GUIDE				
	90311-48014	OIL SEAL									
	11328-75020	GASKET									
11329-75020	GASKET										

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART No.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART No.	PART	SIZE	NOTE
<b>T050K</b>	<b>2TR-FE</b> (2700cc)	13506-75050	CHAIN	124S	06E	<b>T050B</b>	<b>2TR-FE</b>	13506-75050	CHAIN	124S	06E
		13540-75030	TENSIONER					13540-75030	TENSIONER		
		13552-75020	GASKET					13552-75020	GASKET		
		13559-75040	GUIDE		=0C020			13559-75040	GUIDE		=0C020
		13561-75040	GUIDE		=0C020			13561-75040	GUIDE		=0C020
		13566-75010	GUIDE					13566-75010	GUIDE		
		13521-75020	GEAR (CRANK)					13521-75020	GEAR (CRANK)		
		13523-75030	GEAR (CAM)					13523-75030	GEAR (CAM)		
	<b>With Balancer Drive</b>	13507-75030	CHAIN	82S	=0C010		<b>With Balancer Drive</b>	13507-75030	CHAIN	82S	05E
		13550-75010	TENSIONER					13550-75010	TENSIONER		
		13554-75020	GUIDE		=0C010			13554-75020	GUIDE		=0C010
		13562-75010	GUIDE		=0C010			13562-75010	GUIDE		=0C010
		13563-75020	GUIDE		=0C010			13563-75020	GUIDE		=0C010
		90311-48020	OIL SEAL					90311-48020	OIL SEAL		
<b>T051K</b>	<b>2AZ-FE</b> (2400cc)	13506-28011/20	CHAIN	134S	05E	<b>T051B</b>	<b>2AZ-FE</b>	13506-28011/20	CHAIN	134S	05E
		13540-28010	TENSIONER		=0H010			13540-28010	TENSIONER		=0H010
		13552-28010	GASKET					13552-28010	GASKET		
		13559-28010	GUIDE		=0H010			13559-28010	GUIDE		=0H010
	<b>1AZ-FE</b> (2000cc)	13561-28010	GUIDE		=0H010		<b>1AZ-FE</b>	13561-28010	GUIDE		=0H010
		13521-28010/30	GEAR (CRANK)					13521-28010/30	GEAR (CRANK)		
		13523-22020	GEAR (CAM)					13523-22020	GEAR (CAM)		
		13507-28010	CHAIN	52S	215			13507-28010	CHAIN	52S	215
	<b>With Pump Drive</b>	13549-28012	TENSIONER				<b>With Pump Drive</b>	13549-28012	TENSIONER		
		13565-28012	SPRING					13565-28012	SPRING		
		13519-28010	GEAR					13519-28010	GEAR		
		15163-28010	GEAR					15163-28010	GEAR		
		90311-38078	OIL SEAL				90311-38078	OIL SEAL			
<b>T052K</b>	<b>1RZ-E</b> (2000cc)	13506-75010	CHAIN	102S	06E	<b>T052B</b>	<b>1RZ-E</b>	13506-75010	CHAIN	102S	06E
		13540-75020	TENSIONER					13540-75020	TENSIONER		
	<b>2RZ-E</b> (2400cc)	13552-75010	TEN. GASKET				<b>2RZ-E</b>	13552-75010	TEN. GASKET		
		13559-76010	GUIDE					13559-76010	GUIDE		
	<b>13523-75010 GEAR</b>	13561-76020	GUIDE				<b>13523-75010 GEAR</b>	13561-76020	GUIDE		
		13521-75010	GEAR (CRANK)					13521-75010	GEAR (CRANK)		
		13523-75010	GEAR (CAM)					13523-75010	GEAR (CAM)		
		90311-48014	OIL SEAL					90311-48014	OIL SEAL		
		11328-75010	GASKET				11328-75010	GASKET			
		11329-75010	GASKET				11329-75010	GASKET			
<b>T053X</b>	<b>2TZ-FZE</b> (2400cc)	13506-75010	CHAIN	102S	06E	<b>T053B</b>	<b>2TZ-FZE</b>	13506-75010	CHAIN	102S	06E
		13540-75020	TENSIONER					13540-75020	TENSIONER		
		13552-75010	TEN. GASKET					13552-75010	TEN. GASKET		
		13559-76010	GUIDE					13559-76010	GUIDE		
	<b>2TZ-FE</b> (2400cc)	13561-76020	GUIDE				<b>2TZ-FE</b>	13561-76020	GUIDE		
		13523-75010	GEAR (CAM)					13523-75010	GEAR (CAM)		
		90311-48014	OIL SEAL								
		11328-75010	GASKET								
		11329-75010	GASKET				11329-75010	GASKET			
<b>T054K</b>	<b>3SZ-VE</b> (1500cc) (2009 - )	13506-BZ020	CHAIN	132S	05E	<b>T054B</b>	<b>3SZ-VE</b> (2009 - )	13506-BZ020	CHAIN	132S	=B1010
		13545-23022	TENSIONER		=BZ011			13545-23022	TENSIONER		=BZ011
		13566-B1020	GUIDE		=BZ010			13566-B1020	GUIDE		=BZ010
		13591-B1020	GUIDE		=BZ010			13591-B1020	GUIDE		=BZ010
		13521-23040	GEAR (CRANK)		=B1020			13521-23040	GEAR (CRANK)		=B1020
		13523-B1010	GEAR (CAM)		=BZ040			13523-B1010	GEAR (CAM)		=BZ040
		90311-35040	OIL SEAL					90311-35040	OIL SEAL		
<b>T055K</b>	<b>1GR-FE (OLD)</b> (4000cc)	13506-31010	CHAIN	174S	06E	<b>T055B</b>	<b>1GR-FE (OLD)</b>	13506-31010	CHAIN	174S	=AD010
		13507-31010	CHAIN (2pcs)	42S	06E			13507-31010	CHAIN (2pcs)	42S	=AD010
		13540-31011	TENSIONER		=AD011			13540-31011	TENSIONER		=AD011
		91551-80635	BOLT(2pcs)					91551-80635	BOLT(2pcs)		
		13550-31010	TENSIONER		=AD010			13550-31010	TENSIONER		=AD010
	<b>2001 - 08/2009</b>	13560-31010	TENSIONER		=AD010		<b>2001 - 08/2009</b>	13560-31010	TENSIONER		=AD010
		13559-31010	GUIDE		=AD010			13559-31010	GUIDE		=AD010
		13561-31010	GUIDE		=AD010			13561-31010	GUIDE		=AD010
		13562-31010	GUIDE(2pcs)		=AD010			13562-31010	GUIDE(2pcs)		=AD010
		13523-31030	GEAR(2pcs)		=AD010			13523-31030	GEAR(2pcs)		=AD010
		13521-31060	GEAR (CRANK)		=AD010			13521-31060	GEAR (CRANK)		=AD010
		13530-31010/1	GEAR (IDLER)		=0P011			13530-31010/1	GEAR (IDLER)		=0P011
		90311-42045	OIL SEAL					90311-42045	OIL SEAL		

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE		
<b>T056K</b>	<b>1ZR-FE</b> (1600cc)	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>	<b>T056B</b>	<b>1ZR-FE</b>	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>		
		13540-37010/30	TENSIONER		=0T011			<b>2ZR-FE</b>	13540-37010/30	TENSIONER		=0T011	
		13552-37010	TEN. GASKET		=0T010				13552-37010	TEN. GASKET		=0T010	
	<b>2ZR-FE</b> (1800cc)	13559-37010/50	GUIDE		=0T010		<b>Without Pump Drive</b>	13559-37010/50	GUIDE		=0T010		
		13561-37020/50	GUIDE		=0T010			13561-37020/50	GUIDE		=0T010		
	<b>Without Pump Drive</b>	13562-37010/20	GUIDE		=0T010		13562-37010/20	GUIDE		=0T010			
		13521-37010/11	GEAR (CRANK)				13521-37010/11	GEAR (CRANK)					
90311-38089		OIL SEAL											
<b>T057K</b>	<b>1ZR-FE</b> (1600cc)	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>	<b>T057B</b>	<b>1ZR-FE</b> (1600cc)	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>		
		13540-37010/30	TENSIONER		=0T011			<b>2ZR-FE</b> (1800cc)	13540-37010/30	TENSIONER		=0T011	
		13552-37010	TEN. GASKET		=0T010				13552-37010	TEN. GASKET		=0T010	
		13559-37010/50	TENSIONER		=0T010				13559-37010/50	TENSIONER		=0T010	
		<b>2ZR-FE</b> (1800cc)	13561-37020/50	TENSIONER				=0T010	<b>2ZR-FE</b> (1800cc)	13561-37020/50	TENSIONER		=0T010
			13562-37010/20	GUIDE				=0T010		13562-37010/20	GUIDE		=0T010
	<b>With Pump Drive</b>	13521-37010/11	GEAR (CRANK)				<b>With Pump Drive</b>	13521-37010/11	GEAR (CRANK)				
		13507-28010	CHAIN	<b>52S</b>	<b>215</b>			13507-28010	CHAIN	<b>52S</b>	=0H020		
		13549-37010/20	TENSIONER		=0T010			13549-37010/20	TENSIONER		=0T010		
		13565-37010	SPRING		=0T010			13565-37010	SPRING		=0T010		
		13519-37010	GEAR (CRANK)		=0T010			13519-37010	GEAR (CRANK)		=0T010		
	15163-28010	GEAR (PUMP)		=0H050	15163-28010		GEAR (PUMP)		=0H050				
	90311-38089	OIL SEAL			90311-38089		OIL SEAL						
<b>T058K</b>	<b>2ZR-FXE Hybrid</b> (1800cc)	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>	<b>T058B</b>	<b>2ZR-FXE Hybrid</b> (1800cc)	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>		
		13540-37010/30	TENSIONER		=0T011			<b>Without Pump Drive</b>	13540-37010/30	TENSIONER		=0T011	
		13552-37010	TEN. GASKET		=0T010				13552-37010	TEN. GASKET		=0T010	
		<b>Without Pump Drive</b>	13559-37010/50	GUIDE				=0T010	<b>Without Pump Drive</b>	13559-37010/50	GUIDE		=0T010
	13561-37020/50		GUIDE		=0T010		13561-37020/50	GUIDE			=0T010		
	<b>Without Pump Drive</b>	13562-37010/20	GUIDE		=0T010		<b>Without Pump Drive</b>	13562-37010/20	GUIDE		=0T010		
		13521-37010/11	GEAR (CRANK)					13521-37010/11	GEAR (CRANK)				
		13523-22020	GEAR (CAM)					13523-22020	GEAR (CAM)				
90311-38089	OIL SEAL			90311-38089	OIL SEAL								
<b>T059K</b>	<b>2ZR-FXE Hybrid</b> (1800cc)	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>	<b>T059K</b>	<b>2ZR-FXE Hybrid</b> (1800cc)	13506-37010/70	CHAIN	<b>140S</b>	<b>05E</b>		
		13540-37010/30	TENSIONER		=0T011			<b>With Pump Drive</b>	13540-37010/30	TENSIONER		=0T011	
		13552-37010	TEN. GASKET		=0T010				13552-37010	TEN. GASKET		=0T010	
		13559-37010/50	TENSIONER		=0T010				13559-37010/50	TENSIONER		=0T010	
		<b>2ZR-FXE Hybrid</b> (1800cc)	13561-37020/50	TENSIONER				=0T010	<b>2ZR-FXE Hybrid</b> (1800cc)	13561-37020/50	TENSIONER		=0T010
			13562-37010/20	GUIDE				=0T010		13562-37010/20	GUIDE		=0T010
	<b>With Pump Drive</b>	13521-37010/11	GEAR (CRANK)				<b>With Pump Drive</b>	13521-37010/11	GEAR (CRANK)				
		13523-22020	GEAR (CAM)					13523-22020	GEAR (CAM)				
		13507-28010	CHAIN	<b>52S</b>	<b>215</b>			13507-28010	CHAIN	<b>52S</b>	=0H020		
		13549-37010/20	TENSIONER		=0T010			13549-37010/20	TENSIONER		=0T010		
		13565-37010	SPRING		=0T010			13565-37010	SPRING		=0T010		
	13519-37010	GEAR (CRANK)		=0T010	13519-37010		GEAR (CRANK)		=0T010				
	15163-28010	GEAR (PUMP)		=0H050	15163-28010		GEAR (PUMP)		=0H050				
90311-38089	OIL SEAL			90311-38089	OIL SEAL								
<b>T060K</b>	<b>1ZR-FAE</b> (1600cc)	13506-37040/50	CHAIN	<b>134S</b>	=0T100	<b>T060B</b>	<b>1ZR-FAE</b>	13506-37040/50	CHAIN	<b>134S</b>	<b>05E</b>		
		13540-37010/30	TENSIONER		=0T011			<b>2ZR-FAE</b>	13540-37010/30	TENSIONER		=0T011	
		13552-37010	TEN. GASKET		=0T010				13552-37010	TEN. GASKET		=0T010	
	<b>2ZR-FAE</b> (1800cc)	13559-37010/50	GUIDE		=0T010		<b>Without Pump Drive</b>	13559-37010/50	GUIDE		=0T010		
		13561-37040/60	GUIDE		=37010			13561-37040/60	GUIDE		=37010		
	<b>Without Pump Drive</b>	13521-37010/11	GEAR (CRANK)				<b>Without Pump Drive</b>	13521-37010/11	GEAR (CRANK)				
		90311-38089	OIL SEAL					90311-38089	OIL SEAL				
<b>T061K</b>	<b>1ZR-FAE</b> (1600cc)	13506-37040/50	CHAIN	<b>134S</b>	=0T100	<b>T061B</b>	<b>1ZR-FAE</b> (1600cc)	13506-37040/50	CHAIN	<b>134S</b>	<b>05E</b>		
		13540-37010/30	TENSIONER		=0T011			<b>2ZR-FAE</b> (1800cc)	13540-37010/30	TENSIONER		=0T011	
		13552-37010	TEN. GASKET		=0T010				13552-37010	TEN. GASKET		=0T010	
		13559-37010/50	GUIDE		=0T010				13559-37010/50	GUIDE		=0T010	
	<b>2ZR-FAE</b> (1800cc)	13561-37040/60	GUIDE		=37010		<b>2ZR-FAE</b> (1800cc)	13561-37040/60	GUIDE		=37010		
		13521-37010/11	GEAR (CRANK)					13521-37010/11	GEAR (CRANK)				
	<b>With Pump Drive</b>	13507-28010	CHAIN	<b>52S</b>	<b>215</b>		<b>With Pump Drive</b>	13507-28010	CHAIN	<b>52S</b>	=0H020		
		13549-37010/20	TENSIONER		=0T010			13549-37010/20	TENSIONER		=0T010		
		13565-37010	SPRING		=0T010			13565-37010	SPRING		=0T010		
		13519-37010	GEAR (CRANK)		=0T010			13519-37010	GEAR (CRANK)		=0T010		
		15163-28010	GEAR (PUMP)		=0H050			15163-28010	GEAR (PUMP)		=0H050		
	90311-38089	OIL SEAL			90311-38089		OIL SEAL						

**TOYOTA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>T062K</b>	<b>3ZR-FE</b> (2000cc)	13506-37020/90	CHAIN	<b>142S</b>	<b>05E</b>	<b>T062B</b>	<b>3ZR-FE</b>	13506-37020/90	CHAIN	<b>142S</b>	<b>05E</b>
		13540-37010/30	TENSIONER		=0T011			13540-37010/30	TENSIONER		=0T011
		13552-37010	TEN. GASKET		=0T010			13552-37010	TEN. GASKET		=0T010
		13559-37020	GUIDE					13559-37020	GUIDE		
		13561-37020/50	GUIDE		=0T010			13561-37020/50	GUIDE		=0T010
		13562-37010/20	GUIDE		=0T010			13562-37010/20	GUIDE		=0T010
	13521-37020	GEAR (CRANK)			13521-37020		GEAR (CRANK)				
		90311-38089	OIL SEAL								
<b>T063K</b>	<b>3ZR-FE</b> (2000cc)	13506-37020/90	CHAIN	<b>142S</b>	<b>05E</b>	<b>T063B</b>	<b>3ZR-FE</b>	13506-37020/90	CHAIN	<b>142S</b>	<b>05E</b>
		13540-37010/30	TENSIONER		=0T011			13540-37010/30	TENSIONER		=0T011
		13552-37010	TEN. GASKET		=0T010			13552-37010	TEN. GASKET		=0T010
		13559-37020	TENSIONER					13559-37020	TENSIONER		
		13561-37020/50	TESIONER		=0T010			13561-37020/50	TESIONER		=0T010
		13562-37010/20	GUIDE		=0T010			13562-37010/20	GUIDE		=0T010
		13521-37020	GEAR (CRANK)					13521-37020	GEAR (CRANK)		
	<b>With Pump Drive</b>	13507-28010	CHAIN	<b>52S</b>	<b>215</b>		<b>With Pump Drive</b>	13507-28010	CHAIN	<b>52S</b>	<b>=0H020</b>
		13549-37010/20	TENSIONER		=0T010			13549-37010/20	TENSIONER		=0T010
		13565-37010	SPRING		=0T010			13565-37010	SPRING		=0T010
		13519-37010	GEAR (CRANK)		=0T010			13519-37010	GEAR (CRANK)		=0T010
		15163-28010	GEAR (PUMP)		=0H050			15163-28010	GEAR (PUMP)		=0H050
		90311-38089	OIL SEAL					90311-38089	OIL SEAL		
<b>T064K</b>	<b>3ZR-FAE</b> (2000cc)	13506-37030/60	CHAIN	<b>136S</b>	<b>05E</b>	<b>T064B</b>	<b>3ZR-FAE</b>	13506-37030/60	CHAIN	<b>136S</b>	<b>05E</b>
		13540-37010/30	TENSIONER		=0T011			13540-37010/30	TENSIONER		=0T011
		13552-37010	TEN. GASKET		=0T010			13552-37010	TEN. GASKET		=0T010
		13559-37020	GUIDE					13559-37020	GUIDE		
	<b>Without Pump Drive</b>	13561-37040/60	GUIDE		=37010		<b>Without Pump Drive</b>	13561-37040/60	GUIDE		=37010
		13521-37020	GEAR (CRANK)					13521-37010/11	GEAR (CRANK)		
		90311-38089	OIL SEAL								
<b>T065K</b>	<b>3ZR-FAE</b> (2000cc)	13506-37030/60	CHAIN	<b>136S</b>	<b>05E</b>	<b>T065B</b>	<b>3ZR-FAE</b>	13506-37030/60	CHAIN	<b>136S</b>	<b>05E</b>
		13540-37010/30	TENSIONER		=0T011			13540-37010/30	TENSIONER		=0T011
		13552-37010	TEN. GASKET		=0T010			13552-37010	TEN. GASKET		=0T010
		13559-37020	GUIDE					13559-37020	GUIDE		
		13561-37040/60	GUIDE		=37010			13561-37040/60	GUIDE		=37010
		13521-37020	GEAR (CRANK)					13521-37020	CRANK GEAR		
	<b>With Pump Drive</b>	13507-28010	CHAIN	<b>52S</b>	<b>215</b>		<b>With Pump Drive</b>	13507-28010	CHAIN	<b>52S</b>	<b>=0H020</b>
		13549-37010/20	TENSIONER		=0T010			13549-37010/20	TENSIONER		=0T010
		13565-37010	SPRING		=0T010			13565-37010	SPRING		=0T010
		13519-37010	GEAR (CRANK)		=0T010			13519-37010	GEAR (CRANK)		=0T010
		15163-28010	GEAR (PUMP)		=0H050			15163-28010	GEAR (PUMP)		=0H050
		90311-38089	OIL SEAL					90311-38089	OIL SEAL		
		<b>T066K</b>	<b>1KR-FE NEW</b> (1000cc)	13506-40010/20	CHAIN			<b>124S</b>	<b>05E</b>	<b>T066B</b>	<b>1KR-FE NEW</b>
13540-21020	TENSIONER					13540-21020	TENSIONER				
13552-40010	TEN. GASKET					13552-40010	TEN. GASKET				
13566-40020/30	GUIDE					13566-40020/30	GUIDE				
<b>1KR-VET</b> (1000cc)	13591-40040		GUIDE			<b>1KR-VET</b>	13591-40040	GUIDE			
	13521-40020		GEAR (CRANK)				13521-40020	GEAR (CRANK)			
	13523-22020		GEAR (CAM)				13523-22020	GEAR (CAM)			
	90311-38084/92		OIL SEAL								

**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE					
<b>N101K</b>	<b>J13</b> (1300cc)	13028-10601	CHAIN	<b>52D</b>	<b>06B</b>	<b>N101B</b>	<b>J13</b>	13028-10601	CHAIN	<b>52D</b>	<b>06B</b>					
		13070-10600	TENSIONER					13070-10600	TENSIONER							
	<b>J15</b> (1500cc)	13021-30000	GEAR (CRANK)					<b>J15</b>	13021-30000	GEAR (CRANK)						
		13024-30800	GEAR (CAM)						13024-30800	GEAR (CAM)						
		13042-B3000	OIL SEAL													
<b>J16</b> (1600cc)	13044-B3401	GASKET														
<b>N102K</b>	<b>A12</b> (1200cc)	13028-18001	CHAIN	<b>54D</b>	<b>06B</b>	<b>N102B</b>	<b>A12</b>	13028-18001	CHAIN	<b>54D</b>	<b>06B</b>					
		13070-18001	TENSIONER					13070-18001	TENSIONER							
	<b>A14</b> (1400cc)	13021-H8900	GEAR (CRANK)					<b>A14</b>	13021-H8900	GEAR (CRANK)						
		13024-18001	GEAR (CAM)						13024-18001	GEAR (CAM)						
		13510-H1000	OIL SEAL													
<b>A15</b> (1500cc)	13044-H1000	GASKET														
<b>N103K</b>	<b>L16</b> (1600cc)	13028-21000	CHAIN	<b>110D</b>	<b>06B</b>	<b>N103B</b>		13028-21000	CHAIN	<b>110D</b>	<b>06B</b>					
		13070-21002	TENSIONER					13070-21002	TENSIONER							
		13085-21002	GUIDE					<b>L16</b>	13085-21002			GUIDE				
		13091-A3500	GUIDE						<b>L18</b>			13091-A3500	GUIDE			
	<b>L18</b> (1800cc)	13021-U8010	GEAR (CRANK)							13021-U8010	GEAR (CRANK)					
		13024-U8001	GEAR (CAM)						13024-U8001	GEAR (CAM)						
		13042-A3500	OIL SEAL													
		13520-U0100	GASKET													
13521-U0100	GASKET															
<b>N104K</b>	<b>L20B</b> (2000cc)	13028-U6000	CHAIN	<b>114D</b>	<b>06B</b>	<b>N104B</b>		13028-U6000	CHAIN	<b>114D</b>	<b>06B</b>					
		13070-21002	TENSIONER					13070-21002	TENSIONER							
		13085-U6000	GUIDE					<b>L20B</b>	13085-U6000			GUIDE				
		13091-A3500	GUIDE						<b>L20B</b>			13091-A3500	GUIDE			
		13021-U8010	GEAR (CRANK)											13021-U8010	GEAR (CRANK)	
		13024-21000	GEAR (CAM)										13024-21000	GEAR (CAM)		
		13042-A3500	OIL SEAL													
		13520-U6000	GASKET													
13521-U6000	GASKET															
<b>N105K</b>	<b>L24</b> (2400cc)	13028-21000	CHAIN	<b>110D</b>	<b>06B</b>	<b>N105B</b>		13028-21000	CHAIN	<b>110D</b>	<b>06B</b>					
		13070-E3000	TENSIONER					13070-E3000	TENSIONER							
		13085-21002	GUIDE					<b>L24</b>	13085-21002			GUIDE				
		13091-A3500	GUIDE						<b>L26</b>			13091-A3500	GUIDE			
	<b>L26</b> (2600cc)	13021-U8010	GEAR (CRANK)							13021-U8010	GEAR (CRANK)					
		13024-21000	GEAR (CAM)						13024-21000	GEAR (CAM)						
		13042-A3500	OIL SEAL													
		13520-P0100	GASKET													
13521-P0100	GASKET															
<b>N106K</b>	<b>L28</b> (2800cc)	13028-21000	CHAIN	<b>110D</b>	<b>06B</b>	<b>N106B</b>		13028-21000	CHAIN	<b>110D</b>	<b>06B</b>					
		13070-E3000	TENSIONER					13070-E3000	TENSIONER							
		13085-21002	GUIDE					<b>L28</b>	13085-21002			GUIDE				
		13091-N4201	GUIDE						<b>L28E</b>			13091-N4201	GUIDE			
	<b>L28E</b> (2800cc)	13021-U8010	GEAR (CRANK)							13021-U8010	GEAR (CRANK)					
		13024-21000	GEAR (CAM)						13024-21000	GEAR (CAM)						
		13042-A3500	OIL SEAL													
		13520-P0100	GASKET													
13521-P0100	GASKET															
<b>N107K</b>	<b>Z20</b> (2000cc)	13028-N8400	CHAIN	<b>102D</b>	<b>06B</b>	<b>N107B</b>		13028-N8400	CHAIN	<b>102D</b>	<b>06B</b>					
		13070-21002	TENSIONER					13070-21002	TENSIONER							
	<b>Z20E</b> (2000cc)	13085-N8400	GUIDE									<b>Z20</b>	13085-N8400	GUIDE		
		13091-W0400	GUIDE										<b>Z22</b>	13091-W0400	GUIDE	
	<b>Z22</b> (2200cc)	13021-U8010	GEAR (CRANK)									<b>Z22E</b>		13021-U8010	GEAR (CRANK)	
		13024-U8001	GEAR (CAM)										13024-U8001	GEAR (CAM)		
	<b>Z22E</b> (2200cc)	13042-A3500	OIL SEAL													
13520-U6000		GASKET														
13521-U6000		GASKET														
<b>N108K</b>	<b>H20</b> (2000cc)	13028-73600	CHAIN	<b>54D</b>	<b>06B</b>	<b>N108B</b>		13028-73600	CHAIN	<b>54D</b>	<b>06B</b>					
		13070-32200	TENSIONER					13070-32200	TENSIONER							
		13021-73600	GEAR (CRANK)										13021-73600	GEAR (CRANK)		
		13024-78200	GEAR (CAM)										13024-78200	GEAR (CAM)		
		13510-E0700	OIL SEAL													
13520-E0700	GASKET															

**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>N109K</b> <b>Double Chain</b>	<b>Z24</b> (2400cc)	13028-10W00	CHAIN	<b>106D</b>	<b>06B</b>	<b>N109B</b> <b>Double Chain</b>	<b>Z24</b> <b>Z24i</b>	13028-10W00	CHAIN	<b>106D</b>	<b>06B</b>
		13070-21002	TENSIONER					13070-21002	TENSIONER		
		13085-10W10	GUIDE					13085-10W10	GUIDE		
		13091-10W00	GUIDE					13091-10W00	GUIDE		
	<b>Z24i</b> (2400cc)	13021-U8010	GEAR (CRANK)					13021-U8010	GEAR (CRANK)		
		13024-U8001	GEAR (CAM)					13024-U8001	GEAR (CAM)		
		13042-A3500	OIL SEAL								
		13520-10W00	GASKET								
		13521-10W10	GASKET								
<b>N110K</b> <b>Single Chain</b>	<b>Z24i</b> (2400cc)	13028-03G00	CHAIN	<b>106S</b>	<b>06B</b>	<b>N110B</b> <b>Single Chain</b>	<b>Z24i</b>	13028-03G00	CHAIN	<b>106S</b>	<b>06B</b>
		13070-21002	TENSIONER					13070-21002	TENSIONER		
		13085-10W10	GUIDE					13085-10W10	GUIDE		
		13091-10W00	GUIDE					13091-10W00	GUIDE		
		13021-03G00	GEAR (CRANK)					13021-03G00	GEAR (CRANK)		
		13024-03G00	GEAR (CAM)					13024-03G00	GEAR (CAM)		
		13042-A3500	OIL SEAL								
		13520-10W00	GASKET								
		13521-10W10	GASKET								
<b>N111K</b>	<b>GA16i</b> (1600cc) <b>12V</b>	13028-77A01	CHAIN	<b>92S</b>	<b>06B</b>	<b>N111B</b> <b>GA15DS</b> <b>12V</b>		13028-77A01	CHAIN	<b>92S</b>	<b>06B</b>
		13070-77A12	TENSIONER					13070-77A12	TENSIONER		
		13079-53Y00	TEN. GASKET					13079-53Y00	TEN. GASKET		
		13085-77A03	GUIDE					13085-77A03	GUIDE		
		13091-77A01	GUIDE					13091-77A01	GUIDE		
	<b>GA15DS</b> (1500cc) <b>12V</b>	13021-77A00	GEAR (CRANK)					13021-77A00	GEAR (CRANK)		
		13024-77A00	GEAR (CAM)					13024-77A00	GEAR (CAM)		
		13510-77A10	OIL SEAL								
		15053-77A00	O-RING								
		15066-0M300	GASKET(2pcs)								
<b>N114K</b>	<b>Z16</b> (1600cc)	13028-W0400	CHAIN	<b>98D</b>	<b>06B</b>	<b>N114B</b>	<b>Z16</b> <b>Z18</b>	13028-W0400	CHAIN	<b>98D</b>	<b>06B</b>
		13070-21002	TENSIONER					13070-21002	TENSIONER		
		13085-W0400	GUIDE					13085-W0400	GUIDE		
		13091-W0400	GUIDE					13091-W0400	GUIDE		
	<b>Z18</b> (1800cc)	13021-U8010	GEAR (CRANK)					13021-U8010	GEAR (CRANK)		
		13024-U8001	GEAR (CAM)					13024-U8001	GEAR (CAM)		
		13042-A8600	OIL SEAL								
		13520-U0100	GASKET								
		13521-U0100	GASKET								
<b>N115K</b>	<b>KA24E</b> (2400cc)	13028-40F01	CHAIN	<b>102S</b>	<b>06E</b>	<b>N115B</b>	<b>KA24E</b>	13028-40F01	CHAIN	<b>102S</b>	<b>06E</b>
		13070-40F06	TENSIONER					13070-40F06	TENSIONER		
		13085-40F10	GUIDE					13085-40F10	GUIDE		
		13075-40F10	BOLT(2pcs)					13075-40F10	BOLT(2pcs)		
		13091-40F15	GUIDE					13091-40F15	GUIDE		
		13021-40F01	GEAR (CRANK)					13021-40F01	GEAR (CRANK)		
		13024-40F00	GEAR (CAM)					13024-40F00	GEAR (CAM)		
		15066-40F01	GASKET								
		15066-40F11	GASKET								
		13510-40F00	OIL SEAL								
		15059-V5001	O-RING								
		15066-0M300	GASKET								



**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>N116X</b> (- 1993)	<b>GA16DE</b> (1600cc)  <b>Without Idler Gear</b>	13028-53Y00	CHAIN	80S	06E	<b>N116B</b> (- 1993)	<b>GA16DE</b>  <b>Without Idler Gear</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
		13070-53Y13	TENSIONER					13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
		13079-53Y00	TEN. GASKET					13079-53Y00	TEN. GASKET		
		13085-53Y00	GUIDE					13085-53Y00	GUIDE		
		<b>13085-53Y10</b>	<b>GUIDE</b>					<b>13085-53Y10</b>	<b>GUIDE</b>		
		<b>13085-53Y15</b>	<b>GUIDE</b>					<b>13085-53Y15</b>	<b>GUIDE</b>		
		13091-53Y01	GUIDE					13091-53Y01	GUIDE		
		13021-53Y01	GEAR (CRANK)					13021-53Y01	GEAR (CRANK)		
		13024-53Y01	GEAR (CAM)					13024-53Y01	GEAR (CAM)		
		13510-50B10	OIL SEAL								
		15066-0M300	GASKET					2pcs			
<b>N116KF</b> (- 1993)	<b>GA16DE</b> (1600cc)  <b>With Idler Gear</b>	13028-53Y00	CHAIN	80S	06E	<b>N116BF</b> (- 1993)	<b>GA16DE</b>  <b>With Idler Gear</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
		13070-53Y13	TENSIONER					13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
		13079-53Y00	TEN. GASKET					13079-53Y00	TEN. GASKET		
		13085-53Y00	GUIDE					13085-53Y00	GUIDE		
		<b>13085-53Y10</b>	<b>GUIDE</b>					<b>13085-53Y10</b>	<b>GUIDE</b>		
		<b>13085-53Y15</b>	<b>GUIDE</b>					<b>13085-53Y15</b>	<b>GUIDE</b>		
		13091-53Y01	GUIDE					13091-53Y01	GUIDE		
		<b>13077-53Y01</b>	<b>IDLER GEAR</b>					<b>13077-53Y01</b>	<b>IDLER GEAR</b>		=0M200
		13021-53Y01	GEAR (CRANK)					13021-53Y01	GEAR (CRANK)		
		13024-53Y01	GEAR (CAM)					13024-53Y01	GEAR (CAM)		
		13510-50B10	OIL SEAL								
15066-0M300	GASKET			2pcs							
<b>N117X</b> (- 1993)	<b>GA14DE</b> (1400cc)	13028-53Y00	CHAIN	80S	06E	<b>N117B</b> (- 1993)	<b>GA14DE</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
		13070-53Y13	TENSIONER					13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
		13079-53Y00	TEN. GASKET					13079-53Y00	TEN. GASKET		
		13085-53Y00	GUIDE					13085-53Y00	GUIDE		
	<b>GA13DE</b> (1300cc)	<b>13085-53Y10</b>	<b>GUIDE</b>				<b>GA13DE</b>	<b>13085-53Y10</b>	<b>GUIDE</b>		
		<b>13085-53Y15</b>	<b>GUIDE</b>					<b>13085-53Y15</b>	<b>GUIDE</b>		
		13091-53Y01	GUIDE					13091-53Y01	GUIDE		
	<b>Without Idler Gear</b>	13021-53Y01	GEAR (CRANK)				<b>Without Idler Gear</b>	13021-53Y01	GEAR (CRANK)		
		<b>13024-53Y01</b>	<b>GEAR (CAM)</b>		2pcs			<b>13024-53Y01</b>	<b>GEAR (CAM)</b>		2pcs
		13510-50B10	OIL SEAL								
		15066-0M300	GASKET					2pcs			
<b>N117KF</b> (- 1993)	<b>GA14DE</b> (1400cc)	13028-53Y00	CHAIN	80S	06E	<b>N117BF</b> (- 1993)	<b>GA14DE</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
		13070-53Y13	TENSIONER					13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
		13079-53Y00	TEN. GASKET					13079-53Y00	TEN. GASKET		
		13085-53Y00	GUIDE					13085-53Y00	GUIDE		
	<b>GA13DE</b> (1300cc)	<b>13085-53Y10</b>	<b>GUIDE</b>				<b>GA13DE</b>	<b>13085-53Y10</b>	<b>GUIDE</b>		
		<b>13085-53Y15</b>	<b>GUIDE</b>					<b>13085-53Y15</b>	<b>GUIDE</b>		
		13091-53Y01	GUIDE					13091-53Y01	GUIDE		
	<b>With Idler Gear</b>	<b>13077-53Y01</b>	<b>IDLER GEAR</b>				<b>With Idler Gear</b>	<b>13077-53Y01</b>	<b>IDLER GEAR</b>		=0M300
		13021-53Y01	GEAR (CRANK)					13021-53Y01	GEAR (CRANK)		
		<b>13024-53Y01</b>	<b>GEAR (CAM)</b>		2pcs			<b>13024-53Y01</b>	<b>GEAR (CAM)</b>		2pcs
		13510-50B10	OIL SEAL								
15066-0M300	GASKET(2pcs)			2pcs							

**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>N118X</b> (1994 -)	<b>GA16DE</b> (1600cc)	13028-53Y00	CHAIN	80S	06E	<b>N118B</b> (1994 -)	<b>GA16DE</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
		13070-53Y13	TENSIONER					13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
		13079-53Y00	TEN. GASKET					13079-53Y00	TEN. GASKET		
	<b>Without Idler Gear</b>	13085-0M300	GUIDE				13085-0M300	GUIDE			
		13091-53Y01	GUIDE				13091-53Y01	GUIDE			
		13021-53Y01	GEAR (CRANK)				13021-53Y01	GEAR (CRANK)			
		13024-53Y01	GEAR (CAM)				13024-53Y01	GEAR (CAM)			
		13510-50B10	OIL SEAL								
		15066-0M300	GASKET		2pcs						
<b>N118KF</b> (1994 -)	<b>GA16DE</b> (1600cc)	13028-53Y00	CHAIN	80S	06E	<b>N118BF</b> (1994 -)	<b>GA16DE</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
		13070-53Y13	TENSIONER					13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
		13079-53Y00	TEN. GASKET					13079-53Y00	TEN. GASKET		
	<b>With Idler Gear</b>	13085-0M300	GUIDE				13085-0M300	GUIDE			
		13091-53Y01	GUIDE				13091-53Y01	GUIDE			
		13077-53Y01	IDLER GEAR		=0M300		13077-53Y01	IDLER GEAR		=0M300	
		13021-53Y01	GEAR (CRANK)				13021-53Y01	GEAR (CRANK)			
		13024-53Y01	GEAR (CAM)				13024-53Y01	GEAR (CAM)			
		13510-50B10	OIL SEAL								
		15066-0M300	GASKET		2pcs						
<b>N119X</b> (1994 -)	<b>GA14DE</b> (1400cc)	13028-53Y00	CHAIN	80S	06E	<b>N119B</b> (1994 -)	<b>GA14DE</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
	<b>GA13DE</b> (1300cc)	13070-53Y13	TENSIONER				<b>GA13DE</b>	13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
	<b>GA16DNE</b> (Mexico)	13079-53Y00	TEN. GASKET				<b>GA16DNE</b>	13079-53Y00	TEN. GASKET		
		13085-0M300	GUIDE					13085-0M300	GUIDE		
	<b>Without Idler Gear</b>	13091-53Y01	GUIDE				13091-53Y01	GUIDE			
		13021-53Y01	GEAR (CRANK)				13021-53Y01	GEAR (CRANK)			
		13024-53Y01	GEAR (CAM)		2pcs		13024-53Y01	GEAR (CAM)		2pcs	
		13510-50B10	OIL SEAL								
			15066-0M300	GASKET		2pcs					
<b>N119KF</b> (1994 -)	<b>GA14DE</b> (1400cc)	13028-53Y00	CHAIN	80S	06E	<b>N119BF</b> (1994 -)	<b>GA14DE</b>	13028-53Y00	CHAIN	80S	06E
		13028-53Y10	CHAIN	54S	06E			13028-53Y10	CHAIN	54S	06E
	<b>GA13DE</b> (1300cc)	13070-53Y13	TENSIONER				<b>GA13DE</b>	13070-53Y13	TENSIONER		
		13070-53Y00	TENSIONER					13070-53Y00	TENSIONER		
	<b>GA16DNE</b> (Mexico)	13079-53Y00	TEN. GASKET				<b>GA16DNE</b>	13079-53Y00	TEN. GASKET		
		13085-0M300	GUIDE					13085-0M300	GUIDE		
	<b>With Idler Gear</b>	13091-53Y01	GUIDE				13091-53Y01	GUIDE			
		13077-53Y01	IDLER GEAR		=0M300		13077-53Y01	IDLER GEAR		=0M300	
		13021-53Y01	GEAR (CRANK)				13021-53Y01	GEAR (CRANK)			
		13024-53Y01	GEAR (CAM)		2pcs		13024-53Y01	GEAR (CAM)		2pcs	
13510-50B10		OIL SEAL									
		15066-0M300	GASKET		2pcs						

**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	
<b>N120K</b>	<b>Z16 Z16S (1600cc)  Single Chain</b>	13028-15G00	CHAIN	98S	06E	<b>N120B</b>	<b>Z16 Z16S Single</b>	13028-15G00	CHAIN	98S	06E	
		13070-21002	TENSIONER					13070-21002	TENSIONER			
		13085-W0400	GUIDE					13085-W0400	GUIDE			
		13091-W0400	GUIDE					13091-W0400	GUIDE			
		13021-03G00	GEAR (CRANK)					13021-03G00	GEAR (CRANK)			
		13024-03G00	GEAR (CAM)					13024-03G00	GEAR (CAM)			
		13042-A8600	OIL SEAL									
		13520-15G01	GASKET									
		13521-15G01	GASKET									
<b>N121K</b>	<b>Z20 Z20S (2000cc)  Single Chain</b>	13028-67G00	CHAIN	102S	06E	<b>N121B</b>	<b>Z20 Z20S Single</b>	13028-67G00	CHAIN	102S	06E	
		13070-21002	TENSIONER					13070-21002	TENSIONER			
		13085-N8400	GUIDE					13085-N8400	GUIDE			
		13091-W0400	GUIDE					13091-W0400	GUIDE			
		13021-03G00	GEAR (CRANK)					13021-03G00	GEAR (CRANK)			
		13024-03G00	GEAR (CAM)					13024-03G00	GEAR (CAM)			
		13042-A8600	OIL SEAL									
		13520-07N01	GASKET									
		13521-07N01	GASKET									
<b>N122K</b>	<b>NA16S (1600cc)</b>	13028-15G00	CHAIN	98S	06E	<b>N122B</b>	<b>NA16S</b>	13028-15G00	CHAIN	98S	06E	
		13070-21002	TENSIONER					13070-21002	TENSIONER			
		13085-84G00	GUIDE					13085-84G00	GUIDE			
		13091-W0400	GUIDE					13091-W0400	GUIDE			
		13021-03G00	GEAR (CRANK)					13021-03G00	GEAR (CRANK)			
		13024-85G00	GEAR (CAM)					13024-85G00	GEAR (CAM)			
		13042-A8600	OIL SEAL									
		15066-5E500	GASKET									
		15066-85G00	GASKET									
<b>N123K</b>	<b>NA20S (2000cc)</b>	13028-67G00	CHAIN	102S	06E	<b>N123B</b>	<b>NA20S</b>	13028-67G00	CHAIN	102S	06E	
		13070-21002	TENSIONER					13070-21002	TENSIONER			
		13085-85G00	GUIDE					13085-85G00	GUIDE			
		13091-W0400	GUIDE					13091-W0400	GUIDE			
		13021-03G00	GEAR					13021-03G00	GEAR (CRANK)			
		13024-85G00	GEAR					13024-85G00	GEAR (CAM)			
		13042-A8600	OIL SEAL									
		15066-5E500	GASKET									
		15066-85G00	GASKET									
<b>N124X</b>	<b>KA24DE (OLD) (2400cc)</b>	13028-53F02	CHAIN	92S	06E	<b>N124B</b>	<b>KA24DE (OLD)</b>	13028-53F02	CHAIN	92S	=9E000	
		13028-53F11	CHAIN	48D	06E-W			13028-53F11	CHAIN	48D	06E-W	
		13070-53F15	TENSIONER					13070-53F15	TENSIONER			
		13070-4E101	TENSIONER					13070-4E101	TENSIONER			
	<b>Upper Double Chain</b>	13085-53F12	GUIDE				<b>Upper Double Chain</b>	13085-53F12	GUIDE			
		13085-53F15	GUIDE					13085-53F15	GUIDE			
		13085-1E401	GUIDE					13085-1E401	GUIDE			
		13091-9E000	GUIDE					13091-9E000	GUIDE			
	<b>Without Idle Gear</b>	13021-40F01	GEAR (CRANK)				<b>Without Idle Gear</b>	13021-40F01	GEAR (CRANK)			
		13024-53F00	GEAR (CAM)		2pcs			13024-53F00	GEAR (CAM)		2pcs	
		13510-53J01	OIL SEAL									
		15066-5E510	GASKET									
<b>N125X</b>	<b>KA24DE (NEW) (2400cc)</b>	13028-53F02	CHAIN	92S	06E	<b>N125B</b>	<b>KA24DE (NEW)</b>	13028-53F02	CHAIN	92S	=9E000	
		13028-9E010	CHAIN	48S	06E			13028-9E010	CHAIN	48S	06E	
		13070-9E003	TENSIONER					13070-9E003	TENSIONER			
		13070-4E101	TENSIONER					13070-4E101	TENSIONER			
	<b>Upper Single Chain</b>	13085-1E401	GUIDE				<b>Upper Single Chain</b>	13085-1E401	GUIDE			
		13091-9E000	GUIDE					13091-9E000	GUIDE			
		13021-40F01	GEAR (CRANK)					13021-40F01	GEAR (CRANK)	18		
		13024-9E000	GEAR (CAM)		2pcs			13024-9E000	GEAR (CAM)	19	2pcs	
	<b>Without Idle Gear</b>	13510-53J01	OIL SEAL				<b>Without Idle Gear</b>	13510-53J01	OIL SEAL			
		15066-1S701	GASKET					15066-1S701	GASKET			
		15066-1S710	GASKET									

**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	
<b>N125KF</b>	<b>KA24DE</b> (NEW) (2400cc)	13028-53F02	CHAIN	92S	06E	<b>N125BF</b>	<b>KA24DE</b> (NEW) <b>Upper Single Chain</b>	13028-53F02	CHAIN	92S	=9E000	
		13028-9E010	CHAIN	48S	06E			13028-9E010	CHAIN	48S	06E	
		13070-9E003	TENSIONER					13070-9E003	TENSIONER			
		13070-4E101	TENSIONER					13070-4E101	TENSIONER			
		13085-1E401	GUIDE					13085-1E401	GUIDE			
		13091-9E000	GUIDE					13091-9E000	GUIDE			
	<b>Upper Single Chain</b>	13021-40F01	GEAR (CRANK)				<b>With Idler Gear</b>	13021-40F01	GEAR (CRANK)			
		13024-9E000	GEAR (CAM)		2pcs			13024-9E000	GEAR (CAM)		2pcs	
		13077-5V100	<b>IDLER GEAR</b>					13077-5V100	<b>IDLER GEAR</b>			
		13510-53J01	OIL SEAL									
		15066-1S701	GASKET									
		15066-1S710	GASKET									
<b>N126X</b>	<b>CG10DE</b> (1000cc)	13028-41B01	CHAIN	76S	06E	<b>N126B</b>	<b>CG10DE</b>	13028-41B01	CHAIN	76S	=5F601	
		13028-41B10	CHAIN	52S	06E			13028-41B10	CHAIN	52S	=5F611	
		13070-53Y13	TENSIONER		=5F600			13070-53Y13	TENSIONER		=5F600	
	<b>CG13DE</b> (1300cc)	13070-2U501	TENSIONER				<b>CG13DE</b>	13070-2U501	TENSIONER			
		13085-41B00	GUIDE		=99B00			13085-41B00	GUIDE		=99B00	
		13091-41B00	GUIDE		=99B00			13091-41B00	GUIDE		=99B00	
	<b>Without Idler Gear</b>	13021-41B00	GEAR (CRANK)		=5F600		<b>Without Idler Gear</b>	13021-41B00	GEAR (CRANK)		=5F600	
		13024-41B00	GEAR (CAM)	2pcs	=5F600			13024-41B00	GEAR (CAM)	2pcs	=5F600	
		13510-50B10	OIL SEAL		=1F700							
<b>N126KF</b>	<b>CG10DE</b> (1000cc)	13028-41B01	CHAIN	76S	06E	<b>N126BF</b>	<b>CG10DE</b>	13028-41B01	CHAIN	76S	=5F601	
		13028-41B10	CHAIN	52S	06E			13028-41B10	CHAIN	52S	=5F611	
		13070-53Y13	TENSIONER		=5F600			13070-53Y13	TENSIONER			
		13070-2U501	TENSIONER					13070-2U501	TENSIONER			
	<b>CG13DE</b>	13085-41B00	GUIDE		=99B00		<b>CG13DE</b>	13085-41B00	GUIDE		=99B00	
		13091-41B00	GUIDE		=99B00			13091-41B00	GUIDE			
		13021-41B00	GEAR (CRANK)		=5F600			<b>With Idler Gear</b>	13021-41B00	GEAR (CRANK)		
		13024-41B00	GEAR (CAM)	2pcs	=5F600				13024-41B00	GEAR (CAM)		2pcs
			13077-41B01	<b>IDLER GEAR</b>				13077-41B01	<b>IDLER GEAR</b>			
			13510-50B10	OIL SEAL							=1F700	
<b>N127K</b>  <b>Japan Asia</b>	<b>CR12DE</b> (1200cc)	13028-AX001	CHAIN	144S	Silent	<b>N127B</b>  <b>Japan Asia</b>	<b>CR12DE</b>	13028-AX001	CHAIN	144S	Silent	
		13070-AX000	TENSIONER					13070-AX000	TENSIONER			
		13085-AX000	GUIDE					13085-AX000	GUIDE			
		13091-AX000	GUIDE					13091-AX000	GUIDE			
	<b>CR14DE</b> (1400cc)	13021-AX000	GEAR (CRANK)				<b>CR14DE</b>	13021-AX000	GEAR (CRANK)			
		13024-AX000	GEAR (CAM)					13024-AX000	GEAR (CAM)			
		13510-10Y13	OIL SEAL									
<b>N128K</b>  <b>Europe Mexico</b>	<b>CR12DE</b> (1200cc)	13028-AX001	CHAIN	144S	Silent	<b>N128B</b>  <b>Europe Mexico</b>	<b>CR12DE</b>	13028-AX001	CHAIN	144S	Silent	
		(13070-BX000)	TENSIONER					(13070-BX000)	TENSIONER			
		13085-BX000	GUIDE					13085-BX000	GUIDE			
		(13091-BX000)	GUIDE					(13091-BX000)	GUIDE			
	<b>CR14DE</b> (1400cc)	13021-BX000	GEAR (CRANK)				<b>CR14DE</b>	13021-BX000	GEAR (CRANK)			
		13024-BX000	GEAR (CAM)					13024-BX000	GEAR (CAM)			
		13510-1F700	OIL SEAL									
<b>N129X</b>	<b>ZD30DDTi</b> <b>ZD30DD</b> (3000cc) <b>Diesel</b>	13028-2W200	CHAIN	82S	Diesel	<b>N129B II</b> <b>N129X</b> <b>Diesel</b>	<b>ZD30DDTi</b> <b>ZD30DD</b> (3000cc) <b>Diesel</b>	13028-2W200	CHAIN	82S	Diesel	
		13070-2W200	TENSIONER					13070-2W200	TENSIONER			
		13085-2W200	GUIDE					13085-2W200	GUIDE			
		13091-2W200	GUIDE					13091-2W200	GUIDE			
		13095-DC000	GEAR					13095-DC000	GEAR			
		13143-2W203	GEAR					13143-2W203	GEAR			
<b>N130K</b>	<b>QG18DE</b> (1800cc)	13028-8U300	CHAIN	154S	Silent	<b>N130B</b>	<b>QG18DE</b> <b>B15X</b> <b>USA Mexico</b>	13028-8U300	CHAIN	154S	=5M010	
		13070-AU000	TENSIONER		=5M000			13070-AU000	TENSIONER			
		13085-5M000	GUIDE					13085-5M000	GUIDE			
		13085-5M010	GUIDE					13085-5M010	GUIDE			
	<b>B15X USA Mexico</b>	13091-5M000	GUIDE				<b>B15X USA Mexico</b>	13091-5M000	GUIDE			
		13021-5M000	GEAR (CRANK)					13021-5M000	GEAR (CRANK)			
		13024-5M000	GEAR (CAM)		1pc			13024-5M000	GEAR (CAM)		1pc	
		13510-10Y13	OIL SEAL									
		15066-5E510	GASKET		2pcs							

**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
N131K	QG18DE (1800cc)  B15X Special 2 Cam Gears	13028-8U300	CHAIN	154S	Silent	N131B	QG18DE B15X Special 2 Cam Gears	13028-8U300	CHAIN	154S	=5M010
		13070-AU000	TENSIONER		=5M000			13070-AU000	TENSIONER		=5M000
		13085-5M000	GUIDE					13085-5M000	GUIDE		
		13085-5M010	GUIDE					13085-5M010	GUIDE		
		13091-5M000	GUIDE					13091-5M000	GUIDE		
		13021-5M000	GEAR (CRANK)					13021-5M000	GEAR (CRANK)		
		13024-5M000	GEAR (CAM)		2pcs			13024-5M000	GEAR (CAM)		2pcs
		13510-10Y13	OIL SEAL								
		15066-5E510	GASKET(2pcs)		2pcs						
N132K	QG18DE (1800cc)  QG15DE (1500cc)  Asia Europe	13028-4M51A	CHAIN	154S	Silent	N132B	QG18DE  QG15DE  Asia Europe	13028-4M51A	CHAIN	154S	=4M500
		13070-AU000	TENSIONER		=7J600			13070-AU000	TENSIONER		=7J600
		13085-4M500	GUIDE		=7J600			13085-4M500	GUIDE		=7J600
		13085-4M511	GUIDE		=7J610			13085-4M511	GUIDE		=7J610
		13091-4M500	GUIDE		=7J600			13091-4M500	GUIDE		=7J600
		13021-4M501	GEAR (CRANK)		=7J601			13021-4M501	GEAR (CRANK)		=7J601
		13024-4M510	GEAR (CAM)	1pc	=7J600			13024-4M510	GEAR (CAM)	1pc	=7J600
		13510-10Y13	OIL SEAL								
		15066-5E510	GASKET(2pcs)		2pcs						
N133K	QG15DE (1500cc)  QG13DE (1300cc)  Without VVT Eng Asia Europe	13028-4M51A	CHAIN	154S	Silent	N133B	QG15DE QG13DE Without VVT Eng Asia Europe	13028-4M51A	CHAIN	154S	=4M500
		13070-AU000	TENSIONER		=7J600			13070-AU000	TENSIONER		=7J600
		13085-4M500	GUIDE		=7J600			13085-4M500	GUIDE		=7J600
		13085-4M511	GUIDE		=7J610			13085-4M511	GUIDE		=7J610
		13091-4M500	GUIDE		=7J600			13091-4M500	GUIDE		=7J600
		13021-4M501	GEAR (CRANK)		=7J601			13021-4M501	GEAR (CRANK)		=7J601
		13024-4M510	GEAR (CAM)	2pcs	=7J600			13024-4M510	GEAR (CAM)	2pcs	=7J600
		13510-10Y13	OIL SEAL								
		15066-5E510	GASKET(2pcs)		2pcs						
N134K	CR10DE (1000cc)	13028-AX001	CHAIN	144S	Silent	N134B	CR10DE	13028-AX001	CHAIN	144S	Silent
		13070-AX010	TENSIONER					13070-AX010	TENSIONER		
		13085-AX000	GUIDE					13085-AX000	GUIDE		
		13091-AX000	GUIDE					13091-AX000	GUIDE		
		13021-AX000	GEAR (CRANK)					13021-AX000	GEAR (CRANK)		
		13024-AX000	GEAR (CAM)					13024-AX000	GEAR (CAM)		
		13510-10Y13	OIL SEAL								
N135X	ZD30DDT  ZD30DD (3000cc) Diesel	13028-2W200	CHAIN	82S	Diesel	N135B II N135X	ZD30DDT  ZD30DD Diesel	13028-2W200	CHAIN	82S	Diesel
		13070-MA70A	TENSIONER					13070-MA70A	TENSIONER		
		13085-MA70A	GUIDE					13085-MA70A	GUIDE		
		13091-MA70A	GUIDE					13091-MA70A	GUIDE		
		13095-MA70C	GEAR					13095-MA70C	GEAR		
		13143-LC30A	GEAR		=MA70A			13143-LC30A	GEAR		=MA70A
N136K	HR16DE (1600cc)  HR15DE (1500cc)  Without VVT Gear	13028-ED000	CHAIN	152S	Silent	N136B	HR16DE HR15DE  Without VVT Gear	13028-ED000	CHAIN	152S	=1KT0A
		15041-ED000	CHAIN	56S	Silent			15041-ED000	CHAIN	56S	
		13070-ED000	TENSIONER		=1HC0A			13070-ED000	TENSIONER		=1HC0A
		13070-ED010	TENSIONER					13070-ED010	TENSIONER		
		13085-ED000	GUIDE		=1HC2A			13085-ED000	GUIDE		=1HC2A
		13091-ED000	GUIDE		=5H60A			13091-ED000	GUIDE		=5H60A
		13021-ED000	GEAR (CRANK)		=EE50A			13021-ED000	GEAR (CRANK)		=EE50A
		13024-ED000	GEAR (CAM)		=ED50A			13024-ED000	GEAR (CAM)		=ED50A
		15043-ED000	GEAR (PUMP)		=1HC0A			15043-ED000	GEAR (PUMP)		=1HC0A
		13510-ED000	OIL SEAL		=1KT0A						
N137K	HR16DE (1600cc)  HR15DE (1500cc)  Without VVT Gear	13028-ED000	CHAIN	152S	Silent	N137B	HR16DE HR15DE  Without VVT Gear	13028-ED000	CHAIN	152S	=1KT0A
		15041-ED000	CHAIN	56S	Silent			15041-ED000	CHAIN	56S	Silent
		13070-ED000	TENSIONER		=1HC0A			13070-ED000	TENSIONER		=1HC0A
		13070-ED010	TENSIONER					13070-ED010	TENSIONER		
		13085-ED000	GUIDE		=1HC2A			13085-ED000	GUIDE		=1HC2A
		13091-ED000	GUIDE		=5H60A			13091-ED000	GUIDE		=5H60A
		13021-ED000	GEAR (CRANK)		=EE50A			13021-ED000	GEAR (CRANK)		=EE50A
		13024-CJ00B	GEAR (CAM)					13024-CJ00B	GEAR (CAM)		
		15043-ED000	GEAR (PUMP)		=1HC0A			15043-ED000	GEAR (PUMP)		=1HC0A
		13510-ED000	OIL SEAL		=1KT0A						









**NISSAN TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE		
<b>N147K</b>	<b>QR25DE</b> (2500cc)	13028-6N20A (13028-3TU0A)	CHAIN	164S	Silent =1JB0A	<b>N147B</b>	<b>QR25DE</b> (2500cc)	13028-6N20A (13028-3TU0A)	CHAIN	164S	Silent =1JB0A		
		13070-6N21A (13070-6N20A)	TENSIONER					13070-6N21A (13070-6N20A)	TENSIONER				
		13085-6N200	GUIDE					13085-6N200	GUIDE				
	<b>QR20DE</b> (2000cc)	13085-6N210	GUIDE				<b>QR20DE</b> (2000cc)	13085-6N210	GUIDE				
		13085-JG30A	GUIDE		=JA00A			13085-JG30A	GUIDE		=JA00A		
		13091-6N20A (13091-6N200)	GUIDE					13091-6N20A (13091-6N200)	GUIDE				
	<b>13085-6N200</b> <b>Guide</b>	<b>With Balancer Drive</b>	13021-6N20A (13021-6N200)	GEAR (CRANK)			=EA00A	<b>13085-6N200</b> <b>Guide</b>	<b>With Balancer Drive</b>	13021-6N20A (13021-6N200)	GEAR (CRANK)		=EA00A
			13024-6N211 (13024-AU420)	GEAR (CAM)			=EA000			13024-6N211 (13024-AU420)	GEAR (CAM)		=EA000
			15041-JG30A (15041-1JB0A)	CHAIN	66S		Silent			15041-JG30A (15041-1JB0A)	CHAIN	66S	Silent
			13070-JG30A	TENSIONER						13070-JG30A	TENSIONER		
		13024-CK80B (13024-CK80A)	GEAR				13024-CK80B (13024-CK80A)	GEAR					
		13510-6N200	OIL SEAL		=0Z400			13510-6N200	OIL SEAL		=0Z400		
<b>N148K</b>	<b>QR25DE</b> (2500cc)	13028-6N20A (13028-3TU0A)	CHAIN	164S	Silent =1JB0A	<b>N148B</b>	<b>QR25DE</b> (2500cc)	13028-6N20A (13028-3TU0A)	CHAIN	164S	Silent =1JB0A		
		13070-6N21A (13070-6N20A)	TENSIONER					13070-6N21A (13070-6N20A)	TENSIONER				
		13085-1JB1A	GUIDE					13085-1JB1A	GUIDE				
	<b>QR20DE</b> (2000cc)	13085-6N210	GUIDE				<b>QR20DE</b> (2000cc)	13085-6N210	GUIDE				
		13085-JG30A	GUIDE		=JA00A			13085-JG30A	GUIDE		=JA00A		
		13091-1JB1A	GUIDE					13091-1JB1A	GUIDE				
	<b>13085-1JB1A</b> <b>Guide</b>	<b>Main Drive Only</b>	13021-6N20A (13021-6N200)	GEAR (CRANK)			=EA00A	<b>13085-1JB1A</b> <b>Guide</b>	<b>Main Drive Only</b>	13021-6N20A (13021-6N200)	GEAR (CRANK)		=EA00A
			13024-6N211 (13024-AU420)	GEAR (CAM)			=EA000			13024-6N211 (13024-AU420)	GEAR (CAM)		=EA000
			13510-6N200	OIL SEAL			=0Z400			13510-6N200	OIL SEAL		=0Z400
<b>N149K</b>	<b>QR25DE</b> (2500cc)	13028-6N20A (13028-3TU0A)	CHAIN	164S	Silent =1JB0A	<b>N149B</b>	<b>QR25DE</b> (2500cc)	13028-6N20A (13028-3TU0A)	CHAIN	164S	Silent =1JB0A		
		13070-6N21A (13070-6N20A)	TENSIONER					13070-6N21A (13070-6N20A)	TENSIONER				
		13085-1JB1A	GUIDE					13085-1JB1A	GUIDE				
	<b>QR20DE</b> (2000cc)	13085-6N210	GUIDE				<b>QR20DE</b> (2000cc)	13085-6N210	GUIDE				
		13085-JG30A	GUIDE		=JA00A			13085-JG30A	GUIDE		=JA00A		
		13091-1JB1A	GUIDE					13091-1JB1A	GUIDE				
	<b>13085-1JB1A</b> <b>Guide</b>	<b>With Balancer Drive</b>	13021-6N20A (13021-6N200)	GEAR (CRANK)			=EA00A	<b>13085-1JB1A</b> <b>Guide</b>	<b>With Balancer Drive</b>	13021-6N20A (13021-6N200)	GEAR (CRANK)		=EA00A
			13024-6N211 (13024-AU420)	GEAR (CAM)			=EA000			13024-6N211 (13024-AU420)	GEAR (CAM)		=EA000
			15041-JG30A (15041-1JB0A)	CHAIN	66S		Silent			15041-JG30A (15041-1JB0A)	CHAIN	66S	Silent
			13070-JG30A	TENSIONER						13070-JG30A	TENSIONER		
		13024-CK80B (13024-CK80A)	GEAR				13024-CK80B (13024-CK80A)	GEAR					
		13510-6N200	OIL SEAL		=0Z400			13510-6N200	OIL SEAL		=0Z400		

**MAZDA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>M203K</b> ( 74-77 )	<b>B1600NA</b> (1600cc) <b>Double Chain</b>	0453-12-201A	CHAIN	<b>100D</b>		<b>M203B</b> ( 74-77 )	<b>B1600NA</b> <b>Double Chain</b>	0453-12-201A	CHAIN	<b>100D</b>	
		0222-14-151A	CHAIN(PUMP)	<b>46S</b>				0222-14-151A	CHAIN(PUMP)	<b>46S</b>	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0222-12-610	GUIDE					0222-12-610	GUIDE		
		0222-12-660A	GUIDE					0222-12-660A	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0305-11-325A	GEAR					0305-11-325A	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0305-14-143	GEAR					0305-14-143	GEAR		
		0221-10-602B	OIL SEAL								
		0222-10-511	GASKET								
0222-10-512	GASKET										
<b>M204K</b>	<b>E3</b> (1500cc)	0483-23-260	CHAIN	<b>90S</b>		<b>M204B</b>	<b>E3</b>	0483-23-260	CHAIN	<b>90S</b>	
		E301-14-151	CHAIN(PUMP)	<b>52S</b>				E301-14-151	CHAIN(PUMP)	<b>52S</b>	
		E301-12-500B	TENSIONER					E301-12-500B	TENSIONER		
		E301-12-610	GUIDE					E301-12-610	GUIDE		
		E301-12-660	GUIDE					E301-12-660	GUIDE		
		0370-11-321B	GEAR					0370-11-321B	GEAR		
		E301-12-425	GEAR					E301-12-425	GEAR		
		E301-11-323	GEAR					E301-11-323	GEAR		
		E301-14-181	GEAR					E301-14-181	GEAR		
		0187-10-507B	OIL SEAL								
		E301-10-511A	GASKET								
E301-10-512	GASKET										
<b>M205K</b>	<b>B1800VC</b> (1800cc)	0381-12-201	CHAIN	<b>106D</b>		<b>M205B</b>	<b>B1800VC</b>	0381-12-201	CHAIN	<b>106D</b>	
		0222-14-151A	CHAIN(PUMP)	<b>46S</b>				0222-14-151A	CHAIN(PUMP)	<b>46S</b>	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0290-12-610	GUIDE					0290-12-610	GUIDE		
		0290-12-660	GUIDE					0290-12-660	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0305-11-325A	GEAR					0305-11-325A	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0305-14-143	GEAR					0305-14-143	GEAR		
		0221-10-602B	OIL SEAL								
		0222-10-511	GASKET								
0222-10-512	GASKET										
<b>M206K</b> ( 79-80 )	<b>MA</b> (2000cc)	0381-12-201	CHAIN	<b>106D</b>		<b>M206B</b> ( 79-80 )	<b>MA</b>	0381-12-201	CHAIN	<b>106D</b>	
		0222-14-151A	CHAIN(PUMP)	<b>46S</b>				0222-14-151A	CHAIN(PUMP)	<b>46S</b>	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0290-12-610	GUIDE					0290-12-610	GUIDE		
		0290-12-660	GUIDE					0290-12-660	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0305-11-325A	GEAR					0305-11-325A	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0305-14-143	GEAR					0305-14-143	GEAR		
		0221-10-602B	OIL SEAL								
		0290-10-511	GASKET								
0290-10-512	GASKET										

**MAZDA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>M208K</b>	<b>E5</b> (1500cc)	3953-12-401	CHAIN	<b>90D</b>		<b>M208B</b>	<b>E5</b>	3953-12-401	CHAIN	<b>90D</b>	
		E301-14-151	CHAIN(PUMP)	<b>52S</b>				E301-14-151	CHAIN(PUMP)	<b>52S</b>	
		E301-12-500B	TENSIONER					E301-12-500B	TENSIONER		
		E301-12-610	GUIDE					E301-12-610	GUIDE		
		E301-12-660	GUIDE					E301-12-660	GUIDE		
		3953-11-321A	GEAR					3953-11-321A	GEAR		
		E301-11-323	GEAR					E301-11-323	GEAR		
		E303-12-425	GEAR					E303-12-425	GEAR		
		E301-14-181	GEAR					E301-14-181	GEAR		
		0187-10-507B	OIL SEAL								
		E301-10-511A	GASKET								
		E301-10-512	GASKET								
<b>M209K</b>	<b>VB</b> (1800cc)	0381-23-260	CHAIN	<b>106D</b>		<b>M209B</b>	<b>VB</b>	0381-23-260	CHAIN	<b>106D</b>	
		0222-14-151A	CHAIN(PUMP)	<b>46S</b>				0222-14-151A	CHAIN(PUMP)	<b>46S</b>	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0290-12-610	GUIDE					0290-12-610	GUIDE		
		0290-12-660	GUIDE					0290-12-660	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0305-11-325A	GEAR					0305-11-325A	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0305-14-143	GEAR					0305-14-143	GEAR		
		0221-10-602B	OIL SEAL								
		0222-10-511	GASKET								
		0222-10-512	GASKET								
<b>M211K</b> (79-80)	<b>MB</b> (2000cc)	0381-23-260	CHAIN	<b>106D</b>		<b>M211B</b> (79-80)	<b>MB</b>	0381-23-260	CHAIN	<b>106D</b>	
		0222-14-151A	CHAIN(PUMP)	<b>46S</b>				0222-14-151A	CHAIN(PUMP)	<b>46S</b>	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0290-12-610	GUIDE					0290-12-610	GUIDE		
		0290-12-660	GUIDE					0290-12-660	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0305-11-325A	GEAR					0305-11-325A	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0305-14-143	GEAR					0305-14-143	GEAR		
		0221-10-602B	OIL SEAL								
		0290-10-511	GASKET								
		0290-10-512	GASKET								
<b>M212K</b> (80-82)	<b>MB</b> (2000cc)	0381-23-260	CHAIN	<b>106D</b>		<b>M212B</b> (80-82)	<b>MB</b>	0381-23-260	CHAIN	<b>106D</b>	
		0839-14-142	CHAIN(PUMP)	<b>54S</b>				0839-14-142	CHAIN(PUMP)	<b>54S</b>	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0290-12-610C	GUIDE					0290-12-610C	GUIDE		
		0290-12-660	GUIDE					0290-12-660	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0305-11-325B	GEAR					0305-11-325B	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0305-14-143A	GEAR					0305-14-143A	GEAR		
		0221-10-602B	OIL SEAL								
		0222-10-511	GASKET								
		0222-10-512	GASKET								
<b>M213K</b> (82-84)	<b>MA</b> (2000cc)	0381-12-201	CHAIN	<b>106D</b>		<b>M213B</b> (82-84)	<b>MA</b>	0381-12-201	CHAIN	<b>106D</b>	
		0839-14-142	CHAIN(PUMP)	<b>54S</b>				0839-14-142	CHAIN(PUMP)	<b>54S</b>	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0290-12-610C	GUIDE					0290-12-610C	GUIDE		
		0290-12-660	GUIDE					0290-12-660	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0305-11-325B	GEAR					0305-11-325B	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0305-14-143A	GEAR					0305-14-143A	GEAR		
		0221-10-602B	OIL SEAL								
		0290-10-511	GASKET								
		0290-10-512	GASKET								

**MAZDA TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>M214K</b>	<b>TC</b> (1300cc)	0370-12-401	CHAIN	90S		<b>M214B</b>	<b>TC</b>	0370-12-401	CHAIN	90S	
		0324-14-151	CHAIN(PUMP)	44S				0324-14-151	CHAIN(PUMP)	44S	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0370-12-610B	GUIDE					0370-12-610B	GUIDE		
		0324-12-660	GUIDE					0324-12-660	GUIDE		
		0370-11-321	GEAR					0370-11-321	GEAR		
		0370-11-323	GEAR					0370-11-323	GEAR		
		0370-12-425	GEAR					0370-12-425	GEAR		
		0370-14-181	GEAR					0370-14-181	GEAR		
		0187-10-507B	OIL SEAL								
		0324-10-511	GASKET								
0324-10-512	GASKET										
<b>M216K</b>	<b>TC</b> (1300cc) <b>No</b> <b>Oil pump drive</b>	0370-12-401	CHAIN	90S		<b>M216B</b>	<b>TC</b> <b>No</b> <b>Oil pump drive</b>	0370-12-401	CHAIN	90S	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0370-12-610B	GUIDE					0370-12-610B	GUIDE		
		0324-12-660	GUIDE					0324-12-660	GUIDE		
		0370-11-321	GEAR					0370-11-321	GEAR		
		0370-12-425	GEAR					0370-12-425	GEAR		
		0187-10-507B	OIL SEAL								
		0324-10-511	GASKET								
0324-10-512	GASKET										
<b>M217K</b>	<b>MA</b> (2000cc) <b>No</b> <b>Oil pump drive</b>	0381-12-201	CHAIN	90S		<b>M217B</b>	<b>MA</b> <b>No</b> <b>Oil pump drive</b>	0381-12-201	CHAIN	90S	
		3953-12-500A	TENSIONER					3953-12-500A	TENSIONER		
		0290-12-610C	GUIDE					0290-12-610C	GUIDE		
		0290-12-660	GUIDE					0290-12-660	GUIDE		
		0290-11-316	GEAR					0290-11-316	GEAR		
		0222-12-425	GEAR					0222-12-425	GEAR		
		0221-10-602B	OIL SEAL								
		0290-10-511	GASKET								
0290-10-512	GASKET										
<b>M218K</b>	<b>G6</b> (2600cc) <b>Without</b> <b>Balancer</b> <b>Guides</b>	G601-12-201	CHAIN	102S	06E	<b>M218B</b>	<b>G6</b> <b>Without</b> <b>Balancer</b> <b>Guides</b>	G601-12-201	CHAIN	102S	06E
		G601-12-500A	TENSIONER					G601-12-500A	TENSIONER		
		G601-12-611A	GUIDE					G601-12-611A	GUIDE		
		G601-12-671	GUIDE					G601-12-671	GUIDE		
		G601-11-316	GEAR					G601-11-316	GEAR		
		G601-12-425	GEAR					G601-12-425	GEAR		
		JF01-10-602A	OIL SEAL								
		G601-10-502B	GASKET								
G601-10-503B	GASKET										
<b>M219K</b>	<b>G6</b> (2600cc) <b>With</b> <b>Balancer</b> <b>Guides</b>	G601-12-201	CHAIN	102S	06E	<b>M219B</b>	<b>G6</b> <b>With</b> <b>Balancer</b> <b>Guides</b>	G601-12-201	CHAIN	102S	06E
		G601-12-500A	TENSIONER					G601-12-500A	TENSIONER		
		G601-12-611A	GUIDE					G601-12-611A	GUIDE		
		G601-12-671	GUIDE					G601-12-671	GUIDE		
		G601-11-316	GEAR					G601-11-316	GEAR		
		G601-12-425	GEAR					G601-12-425	GEAR		
		G601-11-703A	CHAIN	84S	05T			G601-11-703A	CHAIN	84S	05T
		G601-11-701	GEAR					G601-11-701	GEAR		
		G601-11-751A	GUIDE					G601-11-751A	GUIDE		
		G601-11-771	GUIDE					G601-11-771	GUIDE		
		G613-11-731A	GUIDE					G613-11-731A	GUIDE		
		JF01-10-602A	OIL SEAL								
		G601-10-502B	GASKET								
		G601-10-503B	GASKET								



**MITSUBISHI TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE				
MI301K	4G32 (1600cc)	MD002921	CHAIN	96D		MI301B	4G32	MD002921	CHAIN	96D					
		MD000926	HOLDER					MD000926	HOLDER						
		MD000927	PLUNGER					MD000927	PLUNGER						
		MD000929	SPRING					MD000929	SPRING						
		MF660067	PACKING					MF660067	PACKING						
		MD002930	GUIDE					MD002930	GUIDE						
		MD002935	GUIDE					MD002935	GUIDE						
		MD002728	GEAR					MD002728	GEAR						
		MD002920	GEAR					MD002920	GEAR						
		MD000254	OIL SEAL												
		MD002252	GASKET												
MD002253	GASKET														
MI302K	4G52 (2000cc)	MD021230	CHAIN	102D		MI302B	4G52	MD021230	CHAIN	102D					
		MD021233	TENSIONER					MD021233	TENSIONER						
		MD022235	SPRING					MD022235	SPRING						
		MD021231	GUIDE					MD021231	GUIDE						
		MD021232	GUIDE					MD021232	GUIDE						
		MD020843	GEAR					MD020843	GEAR						
		MD021246	GEAR					MD021246	GEAR						
		MD020308	OIL SEAL												
		MD020324	GASKET												
		MD020325	GASKET												
MI303B	G54B (2600cc) Balancer Only	MD021155	CHAIN	90S											
		MD021111	GUIDE												
		MD021156	GUIDE												
		MD021114	GUIDE												
		MD021170	GEAR												
		MD021172	GEAR (2pcs)		2pcs										
MI304K FULL	4G54 G54B (2600cc)  With Balancer Drive	MD021230	CHAIN	102D		MI304B FULL	4G54 G54B  With Balancer Drive	MD021230	CHAIN	102D					
		MD021155	CHAIN	90S				MD021155	CHAIN	90S					
		MD021233	TENSIONER					MD021233	TENSIONER						
		MD154049	SPRING					MD154049	SPRING						
		MD084945	GUIDE					MD084945	GUIDE						
		MD153644	GUIDE					MD153644	GUIDE						
		MD021232	GUIDE					MD021232	GUIDE						
		MD021111	GUIDE					MD021111	GUIDE						
		MD021156	GUIDE					MD021156	GUIDE						
		MD021114	GUIDE					MD021114	GUIDE						
		MD020843	GEAR					MD020843	GEAR						
		MD021246	GEAR					MD021246	GEAR						
		MD021170	GEAR					MD021170	GEAR						
				MD021172	GEAR (2pcs)				2pcs			MD021172	GEAR (2pcs)		2pcs
				MD020308	OIL SEAL										
		MD020324	GASKET												
		MD020325	GASKET												
MI305K	G52B (2000cc) G54B (2600cc)  Without Balancer Drive	MD021230	CHAIN	102D		MI305B	G52B G54B  Without Balancer Drive	MD021230	CHAIN	102D					
		MD021233	TENSIONER					MD021233	TENSIONER						
		MD154049	SPRING					MD154049	SPRING						
		MD084945	GUIDE					MD084945	GUIDE						
		MD153644	GUIDE					MD153644	GUIDE						
		MD021232	GUIDE					MD021232	GUIDE						
		MD020843	GEAR					MD020843	GEAR						
		MD021246	GEAR					MD021246	GEAR						
		MD020308	OIL SEAL												
		MD020324	GASKET												
MD020325	GASKET														

**MITSUBISHI TIMING KIT CONTENTS**

<b>OSK KIT NO.</b>	<b>ENGINE</b>	<b>PART NO.</b>	<b>PART</b>	<b>SIZE</b>	<b>NOTE</b>	<b>OSK KIT NO.</b>	<b>ENGINE</b>	<b>PART NO.</b>	<b>PART</b>	<b>SIZE</b>	<b>NOTE</b>
<b>MI306X</b>	<b>4M40 (2800cc) Double Chain</b>	ME200244	CHAIN	<b>98D</b>	<b>06B</b>	<b>MI306B II MI306X</b>	<b>4M40  Double Chain</b>	ME200244	CHAIN	<b>98D</b>	<b>06B</b>
		ME200248	TENSIONER					ME200248	TENSIONER		
		ME201853	TEN. GASKET					ME201853	TEN. GASKET		
		ME190013 (ME200476)	GUIDE					ME190013 (ME200476)	GUIDE		
		ME190016 (ME200423)	GUIDE					ME190016 (ME200423)	GUIDE		
		ME200748	GEAR (CAM)					ME200748	GEAR (CAM)		
<b>MI307X</b>	<b>4M40 (2800cc) Single Chain</b>	ME190012	CHAIN	<b>98S</b>	<b>06D</b>	<b>MI307B II MI307X</b>	<b>4M40  Single Chain</b>	ME190012	CHAIN	<b>98S</b>	<b>06D</b>
		ME200248	TENSIONER					ME200248	TENSIONER		
		ME201853	TEN. GASKET					ME201853	TEN. GASKET		
		ME190013 (ME200476)	GUIDE					ME190013 (ME200476)	GUIDE		
		ME190016 (ME200423)	GUIDE					ME190016 (ME200423)	GUIDE		
		ME203099	GEAR (CAM)					ME203099	GEAR (CAM)		
<b>MI308X 3 Guides</b>	<b>4M41-T (3200cc) Single Chain</b>	ME192230 (ME203085)	CHAIN	<b>110S</b>	<b>06D</b>	<b>MI308B II MI308X</b>	<b>4M41-T  Single Chain</b>	ME192230 (ME203085)	CHAIN	<b>110S</b>	<b>06D</b>
		ME203100	TENSIONER					ME203100	TENSIONER		
		ME201853	TEN. GASKET					ME201853	TEN. GASKET		
		ME191029	GUIDE					ME191029	GUIDE		
		ME203833	GUIDE					ME203833	GUIDE		
		ME203096 (1140A026)	GUIDE					ME203096 (1140A026)	GUIDE		
		ME190341	GEAR(CAM)					ME190341	GEAR(CAM)		
ME203099	GEAR (CAM)			ME203099	GEAR (CAM)						
<b>MI309X 4 Guides</b>	<b>4M41-T (3200cc) Single Chain</b>	ME192230 (ME203085)	CHAIN	<b>110S</b>	<b>06D</b>	<b>MI309B II MI309X</b>	<b>4M41-T  Single Chain</b>	ME192230 (ME203085)	CHAIN	<b>110S</b>	<b>06D</b>
		ME203100	TENSIONER					ME203100	TENSIONER		
		ME201853	TEN. GASKET					ME201853	TEN. GASKET		
		ME191029	GUIDE					ME191029	GUIDE		
		ME203833	GUIDE					ME203833	GUIDE		
		ME203093 (1140A041)	GUIDE					ME203093 (1140A041)	GUIDE		
		ME203096 (1140A026)	GUIDE					ME203096 (1140A026)	GUIDE		
		ME190341	GEAR(CAM)					ME190341	GEAR(CAM)		
ME203099	GEAR (CAM)			ME203099	GEAR (CAM)						



**ISUZU TIMING KIT CONTENTS**

OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE	OSK KIT NO.	ENGINE	PART NO.	PART	SIZE	NOTE
<b>I401K</b>	<b>G161Z</b> (1600cc)	8-94200-948-1	CHAIN	<b>92S</b>		<b>I401B</b>	<b>G161Z</b>	8-94200-948-1	CHAIN	<b>92S</b>	
		8-94200-949-1	TENSIONER					8-94200-949-1	TENSIONER		
		8-94201-961-1	GUIDE					8-94201-961-1	GUIDE		
		8-94201-962-2	GUIDE					8-94201-962-2	GUIDE		
		8-94200-972-1	GEAR (CRANK)					8-94200-972-1	GEAR (CRANK)		
		8-94200-973-1	GEAR (CAM)					8-94200-973-1	GEAR (CAM)		
		8-94020-262-0	OIL SEAL								
		8-94202-090-0	GASKET								
		8-94202-091-0	GASKET								
<b>I402K</b>	<b>G180Z</b> (1800cc)	8-94201-047-1	CHAIN	<b>94S</b>		<b>I402B</b>	<b>G180Z</b>	8-94201-047-1	CHAIN	<b>94S</b>	
		8-94200-949-1	TENSIONER					8-94200-949-1	TENSIONER		
		8-94201-961-1	GUIDE					8-94201-961-1	GUIDE		
		8-94201-962-2	GUIDE					8-94201-962-2	GUIDE		
		8-94200-972-1	GEAR (CRANK)					8-94200-972-1	GEAR (CRANK)		
		8-94200-973-1	GEAR (CAM)					8-94200-973-1	GEAR (CAM)		
		8-94020-262-0	OIL SEAL								
		8-94202-090-0	GASKET								
		8-94202-091-0	GASKET								
<b>I403K</b>	<b>G200Z</b> (2000cc)	8-94213-817-0	CHAIN	<b>94S</b>		<b>I403B</b>	<b>G200Z</b>	8-94213-817-0	CHAIN	<b>94S</b>	
		8-94243-322-0	TENSIONER					8-94243-322-0	TENSIONER		
		8-94213-832-0	GUIDE					8-94213-832-0	GUIDE		
		8-94213-819-0	GUIDE					8-94213-819-0	GUIDE		
		8-94213-815-0	GEAR (CRANK)					8-94213-815-0	GEAR (CRANK)		
		8-94213-816-0	GEAR (CAM)					8-94213-816-0	GEAR (CAM)		
		9-09924-296-0	OIL SEAL								
		8-94254-759-0	GASKET								
		8-94254-018-0	GASKET								
<b>I404X</b>	<b>4JJ1-TCM</b> (3000cc) <b>(2004 - 08/2009)</b>	8-97945-067-0	CHAIN	<b>88S</b>	<b>06D</b>	<b>I404B II I404X</b>	<b>4JJ1-TCM</b> <b>(2004 - 08/2009)</b>	8-97945-067-0	CHAIN	<b>88S</b>	<b>06D</b>
		8-97945-068-1	TENSIONER					8-97945-068-1	TENSIONER		
		8-97312-336-0	GASKET					8-97312-336-0	GASKET		
		8-97945-069-0	GUIDE					8-97945-069-0	GUIDE		
		8-97945-070-0	GUIDE					8-97945-070-0	GUIDE		
		8-97312-330-1	GEAR					8-97312-330-1	GEAR		
		8-97312-331-0/1	GEAR					8-97312-331-0/1	GEAR		

**DAIHATSU TIMING KIT CONTENTS**

<b>TD501K</b>	<b>K3-VE</b> <b>K3-DE</b> (1300cc)	13506-97401	CHAIN	<b>158S</b>	<b>Silent</b>	<b>TD501B</b>	<b>K3-VE</b> <b>K3-DE</b>	13506-97401	CHAIN	<b>158S</b>	<b>Silent</b>
		13545-97401	TENSIONER					13545-97401	TENSIONER		
		13566-97401	GUIDE					13566-97401	GUIDE		
		13591-97401	GUIDE					13591-97401	GUIDE		
		13521-97401	GEAR	21				13521-97401	GEAR	21	
		13523-97401	GEAR	42				13523-97401	GEAR	42	
		90311-35040	OIL SEAL								

"TG" SET CONTENTS

LINE	OSK SET NO.	ENGINE	PART NO.	PART	LINE	OSK SET NO.	ENGINE	PART NO.	PART	
TOYOTA	T001TG	KC 3KC	13540-22012 13561-22010	TENSIONER GUIDE	TOYOTA	T035TG	1SZ-FE	13545-23010 13566-23010 13591-23010	TENSIONER GUIDE GUIDE	
	T002TG	4KC	13540-13010 13561-13020	TENSIONER GUIDE		T036TG	3SZ-VE ( - 2008 )	13545-23020 13566-B1020 13591-B1020 13562-B1010	TENSIONER GUIDE GUIDE GUIDE	
	T003TG	2T,3T 3Y,4Y	13540-25010 13561-25010	TENSIONER GUIDE		T037TG	2TR-FE <b>Without Balancer Drive</b>	13540-75030 13552-75020 13559-75040 13561-75040 13566-75010	TENSIONER GASKET GUIDE GUIDE GUIDE	
	T005TG	20R	13540-38012 13561-38010 13562-38010	TENSIONER GUIDE GUIDE		T038TG	2SZ-FE Europe	13545-0J010 13566-23020 13591-23020	TENSIONER GUIDE GUIDE	
	T007TG	18RU	13540-33014 13561-34010 13562-34020 13559-34020	TENSIONER GUIDE GUIDE TENSIONER		T039TG	2SZ-FE Japan	13545-23020 13566-23030 13591-23030	TENSIONER GUIDE GUIDE	
	T008TG	22R	13540-35010 13561-35010 13562-35010	TENSIONER GUIDE GUIDE		T045TG	1KR-FE (OLD)	13540-21020 13566-40020 13591-40020	TENSIONER GUIDE GUIDE	
	T009TG	5R	13540-44010 13561-44010	TENSIONER GUIDE		T046TG	1NZ-FE 13506- 21060 CHAIN	13540-21020 13559-21010 13561-21020 13562-21010	TENSIONER GUIDE GUIDE GUIDE	
	T011TG	22REC 22RTEC	13540-35011 13561-35020 13562-35020	TENSIONER GUIDE GUIDE		T047TG	1NZ-FE 13506- 21050	13540-21020 13559-21030 13561-21040	TENSIONER GUIDE GUIDE	
	T016TG	1RZ-E 2TZ-FE	13540-75010 13552-75010 13559-75011 13561-76010	TENSIONER TEN GASKET GUIDE GUIDE		T048TG	1ND-TV	13540-33020 13559-33010 13561-33020	TENSIONER GUIDE GUIDE	
	T018TG	2RZ-FE 2RZ-E	13540-75020 13552-75010 13559-76010 13561-76020	TENSIONER TEN GASKET GUIDE GUIDE		T049TG	3RZ-FE  <b>With Balancer Drive</b>	13540-75020 13552-75010 13559-75020 13561-75020 13550-75010 13554-75010 13562-75010 13563-75010	TENSIONER TEN GASKET GUIDE GUIDE TENSIONER GUIDE GUIDE	
	T019TG	3RZ-FE <b>Without Balancer Drive</b>	13540-75020 13552-75010 13559-75020 13561-75020	TENSIONER TEN GASKET GUIDE GUIDE		T050TG	2TR-FE  <b>With Balancer Drive</b>	13540-75030 13552-75020 13559-75040 13561-75040 13566-75010 13550-75010 13562-75010 13563-75020	TENSIONER GASKET GUIDE GUIDE GUIDE TENSIONER GUIDE GUIDE	
	T020TG	1FZ-FE	13540-66010 13559-66011 13561-66010	TENSIONER GUIDE GUIDE		T054TG	3SZ-VE (2009-UP)	13545-BZ011 13566-BZ010 13591-BZ010	TENSIONER GUIDE GUIDE	
	T021TG	1ZZ-FE NO VVT	13540-22020 13559-22010 13561-22020	TENSIONER GUIDE GUIDE		T066TG	1KR-FE (NEW)	13540-21020 13552-40010 13566-40030 13591-40040	TENSIONER TEN. GASKET GUIDE GUIDE	
	T022TG	1ZZ-FE VVT	13540-22022 13559-22011 13561-22020	TENSIONER GUIDE GUIDE		T030TG	2AZ-FE 1AZ-FE	13070-21002 13085-21002 13091-A3500	TENSIONER GUIDE GUIDE	
	T024TG	5K	13540-13011 13561-13020	TENSIONER GUIDE		T034TG	1TR-FE	13540-75030 13552-75020 13559-75030 13561-75030 13566-75010	TENSIONER GASKET GUIDE GUIDE GUIDE	
	T025TG	7K	13540-13023 13561-13020	TENSIONER GUIDE						
	T026TG	3ZZ-FE 4ZZ-FE	13540-0D030 13559-22011 13561-22020	TENSIONER GUIDE GUIDE						
	T027TG	1NZ-FE 2NZ-FE	13540-21020 13559-21010 13561-21010	TENSIONER GUIDE GUIDE						
	T029TG	2ZZ-GE	13540-88600 13559-88600 13561-88600	TENSIONER GUIDE GUIDE		NISSAN	N103TG	L16 L18	13070-21002 13085-21002 13091-A3500	TENSIONER GUIDE GUIDE
	T030TG	2AZ-FE 1AZ-FE	13540-28010 13552-28010 13559-28010 13561-28010	TENSIONER GASKET GUIDE GUIDE			N104TG	L20B	13070-21002 13085-U6000 13091-A3500	TENSIONER GUIDE GUIDE
	T034TG	1TR-FE	13540-75030 13552-75020 13559-75030 13561-75030 13566-75010	TENSIONER GASKET GUIDE GUIDE GUIDE			N105TG	L24 L26	13070-E3000 13085-21002 13091-A3500	TENSIONER GUIDE GUIDE
							N106TG	L28	13070-E3000 13085-21002 13091-N4201	TENSIONER GUIDE GUIDE

**"TG" SET CONTENTS**

LINE	OSK SET NO.	ENGINE	PART NO.	PART	LINE	OSK SET NO.	ENGINE	PART NO.	PART
NISSAN	N107TG	Z20,Z20E Z22,Z22E	13070-21002 13085-N8401 13091-W0400	TENSIONER GUIDE GUIDE	NISSAN	N134TG	CR10DE	13070-AX010 13085-AX000 13091-AX000	TENSIONER GUIDE GUIDE
	N109TG	Z24 Z24i	13070-21002 13085-10W10 13091-10W00	TENSIONER GUIDE GUIDE		N135TG	ZD30DDTi	13070-MA70A 13085-MA70A 13091-MA70A	TENSIONER GUIDE GUIDE
	N111TG	GA16i GA15DS	13070-77A12 13079-53Y00 13085-77A03 13091-77A01	TENSIONER TEN. GASKET GUIDE GUIDE	MAZDA	M203TG	B1600NA '74-'77	3953-12-500A 0222-12-610 0222-12-660A	TENSIONER GUIDE GUIDE
	N115TG	KA24E	13070-40F06 13085-40F10 13075-40F10 13091-40F15	TENSIONER GUIDE BOLT(2pcs) GUIDE		M204TG	E3 E5	E301-12-500B E301-12-610 E301-12-660	TENSIONER GUIDE GUIDE
	N116TG	GA16DE GA14DE GA13DE	13070-53Y00 13079-53Y00 13070-53Y13 13085-53Y00 13085-53Y10 13085-53Y15 13091-53Y01	TENSIONER TEN. GASKET TENSIONER GUIDE GUIDE GUIDE GUIDE		M205TG	VC VB	3953-12-500A 0290-12-610 0290-12-660	TENSIONER GUIDE GUIDE
	N118TG	GA16DE GA14DE GA13DE	13070-53Y00 13079-53Y00 13070-53Y13 13085-0M300 08120-8161E 13091-53Y01	TENSIONER TEN. GASKET TENSIONER GUIDE BOLT(2pcs) GUIDE		M206TG	MA MB	3953-12-500A 0290-12-610 0290-12-660	TENSIONER GUIDE GUIDE
	N120TG	Z16 Z16S	13070-21002 13085-W0400 13091-W0400	TENSIONER GUIDE GUIDE		M213TG	MA	3953-12-500A 0290-12-610C	TENSIONER GUIDE
	N121TG	Z20 Z20S	13070-21002 13085-N8400 13091-W0400	TENSIONER GUIDE GUIDE		M218TG	G6 Without Balancer	G601-12-500A G601-12-611A G601-12-671	TENSIONER GUIDE GUIDE
	N122TG	NA16S	13070-21002 13085-84G00 13091-W0400	TENSIONER GUIDE GUIDE		M219TG	G6 With Balancer Guides	G601-12-500A G601-12-611A G601-12-671 G601-11-751A G601-11-771 G613-11-731A	TENSIONER GUIDE GUIDE GUIDE GUIDE GUIDE
	N123TG	NA20S	13070-21002 13085-85G00 13091-W0400	TENSIONER GUIDE GUIDE		M220TG	ZJ-VE ZY-VE	ZJ01-12-500B ZJ01-12-610 ZY08-12-670A	TENSIONER GUIDE GUIDE
	N124TG	KA24DE (OLD)	13070-53F15 13070-4E101 13085-53F12 13085-53F15 13085-1E401 13091-9E000	TENSIONER TENSIONER GUIDE GUIDE GUIDE GUIDE					
	N125TG	KA24DE (NEW)	13070-9E003 13070-4E101 13085-1E401 13091-9E000	TENSIONER TENSIONER GUIDE GUIDE					
	N126TG	CG10DE CG13DE	13070-53Y13 13070-2U501 13085-41B00 13091-41B00	TENSIONER TENSIONER GUIDE GUIDE					
	N127TG	CR12DE CR14DE	13070-AX000 13085-AX000 13091-AX000	TENSIONER GUIDE GUIDE					
	N129TG	ZD30DDTi	13070-2W200 13085-2W200 13091-2W200	TENSIONER GUIDE GUIDE					
	N130TG	QG18DE B15X	13070-AU000 13085-5M000 13085-5M010 13091-5M000	TENSIONER GUIDE GUIDE GUIDE					
N132TG	QG18DE QG15DE QG13DE	13070-AU000 13085-4M500 13085-4M511 13091-4M500	TENSIONER GUIDE GUIDE GUIDE						

**"TG" SET CONTENTS**

LINE	OSK SET NO.	ENGINE	PART NO.	PART	LINE	OSK SET NO.	ENGINE	PART NO.	PART	
MITSUBISHI	MI301TG	4G32	MD000926	HOLDER						
			MD000927	PLUNGER						
			MD000929	SPRING						
			MF660067	PACKING						
			MD002935	GUIDE						
				MD002930	GUIDE					
		MI302TG	4G52	MD021233	TENSIONER					
	MD022235			SPRING						
	MD021231			GUIDE						
				MD021232	GUIDE					
	MI304TG	G52B G54B	MD021233	TENSIONER						
MD154049			SPRING							
MD084945			GUIDE							
MD153644			GUIDE							
MD021232			GUIDE							
MD021111			GUIDE							
			MD021114	GUIDE						
			MD021156	GUIDE						
	MI305TG	G52B G54B Without Balancer	MD021233	TENSIONER						
MD154049			SPRING							
MD084945			GUIDE							
MD153644			GUIDE							
			MD021232	GUIDE						
	MI306TG	4M40	ME200248	TENSIONER						
ME201853			GASKET							
ME190013			GUIDE							
ME190016			GUIDE							
	MI308TG 3 Guides	4M41-T	ME203100	TENSIONER						
ME201853			GASKET							
ME191029			GUIDE							
ME203096			GUIDE							
(1140A026)										
			ME203833	GUIDE						
	MI309TG 4 Guides	4M41-T	ME203100	TENSIONER						
ME201853			GASKET							
ME191029			GUIDE							
ME203093			GUIDE							
(1140A041)										
ME203096			GUIDE							
			(1140A026)							
			ME203833	GUIDE						
ISUZU	I401TG	G161Z G180Z	8-94200-949-1	TENSIONER						
			8-94201-961-1	GUIDE						
			8-94201-962-2	GUIDE						
	I403TG	G200Z	8-94243-322-0	TENSIONER						
8-94213-832-0			GUIDE							
8-94213-819-0			GUIDE							
	I404TG	4JJ1 (2004- 08/2009)	8-97945-068-1	TENSIONER						
8-97312-336-0			GASKET							
8-97945-069-0			GUIDE							
8-97945-070-0			GUIDE							
DAIHATSU	TD501TG	K3-VE K3-DE	13545-97401	TENSIONER						
			13566-97401	GUIDE						
			13591-97401	GUIDE						
SUZUKI	S601TG	J18A J20A	12831-77E02	TENSIONER						
			12832-77E00	TENSIONER						
			12771-77E00	GUIDE						
			12772-77E01	GUIDE						
			12811-77E00	GUIDE						

## "G" SET CONTENTS

LINE	OSK SET NO.	ENGINE	PART NO.	PART	LINE	OSK SET NO.	ENGINE	PART NO.	PART
TOYOTA	T004G	4ME,5ME	13561-45010 13562-45010	GUIDE GUIDE	TOYOTA	T054G	3SZ-VE (2009-UP)	13566-BZ010 13591-BZ010	GUIDE GUIDE
	T005G	20R	13561-38010 13562-38010	GUIDE GUIDE		T066G	1KR-FE (NEW)	13566-40020/30 13591-40040	GUIDE GUIDE
	T007G	18RU	13561-34010 13562-34020 13559-34020	GUIDE GUIDE TENSIONER	NISSAN	N100G	TB42S	13085-03J00 15071-03J00 15073-03J00	GUIDE GUIDE GUIDE
	T008G	22R	13561-35010 13562-35010	GUIDE GUIDE		N103G	L16,18 L24,26	13085-21002 13091-A3500	GUIDE GUIDE
	T011G	22REC 22RTEC	13561-35020 13562-35020	GUIDE GUIDE		N104G	L20B	13085-U6000 13091-A3500	GUIDE GUIDE
	T016G	1RZ-E 2TZ-FE	13559-75011 13561-76010	GUIDE GUIDE		N106G	L28	13085-21002 13091-N4201	GUIDE GUIDE
	T018G	2RZ-FE	13559-76010 13561-76020	GUIDE GUIDE		N107G	Z20,20E Z22,22E	13085-N8401 13091-W0400	GUIDE GUIDE
	T019G	3RZ-FE	13559-75020 13561-75020	GUIDE GUIDE		N109G	Z24,Z24i	13085-10W10 13091-10W00	GUIDE GUIDE
	T020G	1FZ-FE	13559-66011 13561-66010	GUIDE GUIDE		N111G	GA16i GA15DS	13085-77A03 13091-77A01	GUIDE GUIDE
	T021G	1ZZ-FE	13559-22010 13561-22020	GUIDE GUIDE		N115G	KA24E	13085-40F10 13075-40F10 13091-40F15	GUIDE GUIDE BOLT(2pcs) GUIDE
	T022G	1ZZ-FE	13559-22011 13561-22020	GUIDE GUIDE		N116G	GA16DE GA14DE GA13DE	13085-53Y00 13085-53Y10 13085-53Y15 13091-53Y01	GUIDE GUIDE GUIDE GUIDE
	T027G	1NZ-FE 2NZ-FE	13559-21010 13561-21010	GUIDE GUIDE		N118G	GA16DE GA14DE GA13DE	13085-0M300 08120-8161E 13091-53Y01	GUIDE GUIDE BOLT(2pcs) GUIDE
	T029G	2ZZ-GE	13559-88600 13561-88600	GUIDE GUIDE		N120G	Z16 Z16S	13085-W0400 13091-W0400	GUIDE GUIDE
	T030G	2AZ-FE 1AZ-FE	13559-28010 13561-28010	GUIDE GUIDE		N121G	Z20 Z20S	13085-N8400 13091-W0400	GUIDE GUIDE
	T034G	1TR-FE	13559-75030 13561-75030 13566-75010	GUIDE GUIDE GUIDE		N122G	NA16S	13085-84G00 13091-W0400	GUIDE GUIDE
	T035G	1SZ-FE	13566-23010 13591-23010	GUIDE GUIDE		N123G	NA20S	13085-85G00 13091-W0400	GUIDE GUIDE
	T036G	3SZ-VE (- 2008)	13566-B1020 13591-B1020 13562-B1010	GUIDE GUIDE GUIDE		N124G	KA24DE (OLD)	13085-53F12 13085-53F15 13085-1E401 13091-9E000	GUIDE GUIDE GUIDE GUIDE
	T037G	2TR-FE	13559-75040 13561-75040 13566-75010	GUIDE GUIDE GUIDE		N125G	KA24DE (NEW)	13085-1E401 13091-9E000	GUIDE GUIDE
	T038G	2SZ-FE Europe	13566-23020 13591-23020	GUIDE GUIDE		N126G	CG10DE CG13DE	13085-41B00 13091-41B00	GUIDE GUIDE
	T039G	2SZ-FE Japan	13566-23030 13591-23030 13562-23010	GUIDE GUIDE GUIDE		N127G	CR12DE CR14DE	13085-AX000 13091-AX000	GUIDE GUIDE
	T045G	1KR-FE	13566-40020 13591-40020	GUIDE GUIDE		N129G	ZD30DDTi ZD30DD	13085-2W200 13091-2W200	GUIDE GUIDE
	T046G	1NZ-FE	13559-21010 13561-21020 13562-21010	GUIDE GUIDE GUIDE		N130G	QG18DE B15X	13085-5M000 13085-5M010 13091-5M000	GUIDE GUIDE GUIDE
	T047G	1NZ-FE	13559-21030 13561-21040	GUIDE GUIDE		N132G	QG18DE QG15DE QG13DE	13085-4M500 13085-4M511 13091-4M500	GUIDE GUIDE GUIDE
	T048G	1ND-TV	13559-33010 13561-33020	GUIDE GUIDE		N135G	ZD30DDTi ZD30DD	13085-MA70A 13091-MA70A	GUIDE GUIDE
	T049G	3RZ-FE With Balancer Drive	13559-75020 13561-75020 13554-75010 13562-75010 13563-75010	GUIDE GUIDE GUIDE GUIDE GUIDE					
	T050G	2TR-FE With Balancer Drive	13559-75040 13561-75040 13566-75010 13554-75020 13562-75010 13563-75020	GUIDE GUIDE GUIDE GUIDE GUIDE GUIDE					

**"G" SET CONTENTS**

LINE	OSK SET NO.	ENGINE	PART NO.	PART	LINE	OSK SET NO.	ENGINE	PART NO.	PART
MAZDA	M203G	B1600NA '74-'77	0222-12-610 0222-12-660A	GUIDE GUIDE					
	M204G	E3 E5	E301-12-610 E301-12-660	GUIDE GUIDE					
	M205G	VC,MA MB	0290-12-610 0290-12-660	GUIDE GUIDE					
	M213G	MA	0290-12-610C 0290-12-660	GUIDE GUIDE					
	M218G	G6	G601-12-611A G601-12-671	GUIDE GUIDE					
	M219G with Balancer Guides	G6	G601-12-611A G601-12-671 G601-11-751A G601-11-771 G613-11-731A	GUIDE GUIDE GUIDE GUIDE GUIDE					
	M220G	ZJ-VE ZY-VE	ZJ01-12-610 ZY08-12-670/A	GUIDE GUIDE					
	MITSUBISHI	MI301G	4G32	MD002935 MD002930	GUIDE GUIDE				
MI302G		4G52	MD021231 MD021232	GUIDE GUIDE					
MI303G		G52B G54B	MD021111 MD021114 MD021156	GUIDE GUIDE GUIDE					
MI304G		G52B G54B	MD153644 MD021232 MD021111 MD021114 MD021156	GUIDE GUIDE GUIDE GUIDE GUIDE					
MI305G		G52B G54B	MD153644 MD021232	GUIDE GUIDE					
MI306G		4M40	ME190013 (ME200476) ME190013 (ME200423)	GUIDE  GUIDE					
MI308G 3 Guides		4M41-T	ME191029 ME203096 (1140A026) ME203833	GUIDE GUIDE  GUIDE					
MI309G 4 Guides		4M41-T	ME191029 ME203093 (1140A041) ME203096 (1140A026) ME203833	GUIDE GUIDE  GUIDE GUIDE					
ISUZU		I401G	G161Z G180Z	8-94201-961-1 8-94202-962-2	GUIDE GUIDE				
	I403G	G200Z	8-94213-819-0 8-94213-832-0	GUIDE GUIDE					
	I404G	4JJ1	8-97945-069-0	GUIDE					
			8-97945-070-0	GUIDE					
DAIHATSU	TD501G	K3-VE	13566-97401 13591-97401	GUIDE GUIDE					
SUZUKI	S601G	J18A , J20A	12771-77E00 12772-77E01 12811-77E00	GUIDE GUIDE GUIDE					

**"S" SET CONTENTS**

LINE	OSK SET NO.	ENGINE	PART NO.	PART	LINE	OSK SET NO.	ENGINE	PART NO.	PART		
TOYOTA	T001S	KC	13521-22010	GEAR	NISSAN	N115S	KA24E	13021-40F01	GEAR		
		3KC	13523-22010	GEAR					13024-40F00	GEAR	
	T002S	4KC	13521-13020	GEAR		N123S	NA16S	13021-03G00	GEAR		
			13523-13030	GEAR				NA20S	13024-85G00	GEAR	
	T003S	2T,3T,5R	13521-33010	GEAR		N129S	ZD30DDTi	13095-DC000	GEAR		
		3Y,4Y	13522-33010	GEAR					13143-2W203	GEAR	
	T004S	4ME	13521-41011	GEAR		N135S	ZD30DDTi	13095-MA70C	GEAR		
		5ME	13523-43010	GEAR					13143-MA70A	GEAR	
			13522-41011	GEAR		MAZDA	M203S	B1600NA	0290-11-316	GEAR	
	T005S	20R	13521-38010	GEAR						'74-'77	0305-11-325A
			13523-38011	GEAR					VB,VC	0222-12-425	GEAR
	T006S	8RC,18RC	13521-33010	GEAR				MA	0305-14-143	GEAR	
		18RU	13523-33010	GEAR	M204S		E3	0370-11-321B	GEAR		
			13528-33010	GEAR					E301-12-425	GEAR	
			13522-33010	GEAR				E301-11-323	GEAR		
	T008S	22R	13521-35010	GEAR				E301-14-181	GEAR		
			13523-35010	GEAR	M208S		E5	3953-11-321A	GEAR		
	T011S	22REC	13521-35010	GEAR					E303-12-425	GEAR	
		22RTEC	13523-35020	GEAR				E301-11-323	GEAR		
	T014S	4KEC	13521-13040	GEAR			E301-14-181	GEAR			
			13523-13030	GEAR	M212S	MA	0290-11-316	GEAR			
	T016S	1RZ-E	13521-75010	GEAR			MB	0305-11-325B	GEAR		
		3RZ-FE	13523-75010	GEAR				0222-12-425	GEAR		
	T018S	2RZ-FE	13521-75010	GEAR			0305-14-143A	GEAR			
		2RZ-E	13523-75020	GEAR	M218S	G6	G601-11-316	GEAR			
	T020S	1FZ-FE	13521-66020	GEAR				G601-12-425	GEAR		
			13523-66020	GEAR	MITSUBISHI	MI301S	4G32	MD002728	GEAR		
	T021S	1ZZ-FE	13521-22020	GEAR					MD002920	GEAR	
			13523-22020	GEAR (2pcs)		MI302S	4G52	MD020843	GEAR		
	T022S	1ZZ-FE	13521-0D010	GEAR					MD021246	GEAR	
			13523-0D010	GEAR		MI303S	G52B	MD021170	GEAR		
	T023S	1ZZ-FE	13521-0D010	GEAR			G54B	MD021172	GEAR (2pcs)		
		13523-0D010	GEAR (2pcs)	MI304S	G52B	MD020843	GEAR				
T025S	7K 7KE	13521-06010	GEAR			G54B	MD021246	GEAR			
		13523-13030	GEAR				MD021170	GEAR			
T026S	3ZZ-FE	13521-0D010	GEAR			MD021172	GEAR (2pcs)				
	4ZZ-FE	13523-0D010	GEAR	ISUZU	I401S	G161Z	8-94200-972-1	GEAR			
T030S	1AZ-FE	13521-28010	GEAR					G180Z	8-94200-973-0	GEAR	
		13523-28030	GEAR	I403S	G200Z	8-94213-815-0	GEAR				
		13523-22020	GEAR				8-94213-816-0	GEAR			
T031S	2AZ-FE	13521-28010	GEAR	DAIHATSU	TD501S	K3-VE	13521-97401	GEAR			
	1AZ-FE	13523-22020	GEAR					13523-97401	GEAR		
T034S	1TR-FE	12521-75020	GEAR	SUZUKI	S601S	J18A,J20A	12631-77E00	GEAR			
		13523-75030	GEAR					12741-77E00	GEAR (2pcs)		
T035S	1SZ-FE	13521-23010	GEAR								
		13523-23050	GEAR								
T036S	3SZ-VE	13521-23030	GEAR								
		13523-B1010	GEAR								
T037S	2TR-FE	13521-75020	GEAR								
		13523-75030	GEAR								
T048S	1ND-TV	13521-33020	GEAR								
		13523-33021	GEAR								
NISSAN	N101S	J13,15,16	13021-30000	GEAR							
			13024-30800	GEAR							
	N102S	A12,14,15	13021-H8900	GEAR							
			13024-18001	GEAR							
	N103S	L16,18,20B	13021-U8010	GEAR							
		L24,26,Z24	13024-21000	GEAR							
N108S	H20	13021-73600	GEAR								
		13024-78200	GEAR								
N110S	Z24i	13021-03G00	GEAR								
	SINGLE	13024-03G00	GEAR								
N111S	GA16i	13021-77A00	GEAR								
	GA15DS	13024-77A00	GEAR								

## TENSIONER

TOYOTA	NISSAN	MAZDA	MITSUBISHI	ISUZU
13540-0C010	13070-10600	0324-12-500C	1141A035/045	8-94200-949-1
13540-0D030	13070-18001/H1001	3953-12-500A	MD002930	8-94243-322-0
13540-13010	13070-1HC0A/1A	AM01-12-500	MD021233/40	8-97945-068-1
13540-13011	13070-1KT0A/3HC1A	E301-12-500B	MD021234	
13540-13023	13070-21000/2	G601-12-500A	MD084945	
13540-21010	13070-2U501	ZJ01-12-500B	MD154049	
13540-21020(0Q010)	13070-2U50A		ME200248	
13540-22010/2	13070-2W200		ME203100	
13540-22020(30mm)	13070-32200			
13540-22022(28.5mm)	13070-3HC0A/0B			<b>SUZUKI</b>
13540-25010	13070-40F06			13831-77E02
13540-28010/0H010	13070-4E101			13832-77E00
13540-31010	13070-4E102			
13540-31011/AD011	13070-4M500			
13540-33014	13070-53F15			
13540-33020/0N010	13070-53F16			<b>DAIHATSU</b>
13540-35010/1	13070-53Y00			13545-97401(-000)
13540-37010/30	13070-53Y10/13			
13540-38010/1/2	13070-5M000			
13540-44010	13070-6N20A/6N21A			
13540-66011	13070-6N215			
13540-75010	13070-77A12			
13540-75020	13070-7J600			
13540-75030	13070-9E003			
13540-88600	13070-AD503			
13540-0T011/0T040	13070-AN200			
13545-0J010	13070-AN201			
13545-23010	13070-AU000			
13545-23020	13070-AX000			
13545-23022	13070-AX010			
13545-97401	13070-C6000			
13545-BZ010/011	13070-E3000/1			
13549-28012/0H010	13070-ED000/9U50A			
13550-31010/AD010	13070-ED010/EE51A			
13550-75010	13070-JG30A			
13559-34020	13070-MA70A			
13560-31010/AD010				
13565-28012				
13549-37010/20				
13549-0T010/0T040				



## GUIDE (DAMPER)

TOYOTA	TOYOTA	NISSAN	NISSAN
13554-75010	13561-44010	13085-03J00	13091-10W00
13554-75020/0C010	13561-45010	13085-0M300	13091-1HC0A/1A
	13561-66010	13085-10W10	13091-2W200
13559-0C010	13561-75020	13085-1E401	13091-40F10/5
13559-0C020	13561-75030	13085-1HC0A/1A	13091-41B00
13559-0D010	13561-75040	13085-21002	13091-4M500
13559-0M010	13561-76010	13085-2W200	13091-53Y00/1
13559-21010	13561-76020	13085-40F10	13091-5M000
13559-21030	13561-88600	13085-41B00	13091-6N200/20A
13559-22010		13085-4M500	13091-77A01
13559-22011	13562-21010	13085-4M511	13091-7J600
13559-28010	13562-23010	13085-53F12	13091-8J000/JA00A
13559-31010/AD010	13562-34020	13085-53F15	13091-99B00
13559-33010/0N010	13562-35010	13085-53Y00	13091-9E000
13559-34020	13562-35020	13085-53Y10	13091-A3500
13559-37010/37050	13562-38010	13085-53Y15	13091-AX000
13559-37020/37030	13562-45010	13085-5M000	13091-ED000/5H60A
13559-66011	13562-B1010	13085-5M010	13091-MA70A
13559-75011	13562-37010/20	13085-6N200	13091-N4201
13559-75020	13562-75010/0C010	13085-6N210	13091-W0400
13559-75030	13562-31010/AD010	13085-77A03	13091-1JB1A
13559-75040	13562-0T010/0T040	13085-77A04	
13559-76010		13085-7J600	15071-03J00
13559-88600	13563-75010	13085-7J60A	15073-03J00
13559-0T010/0T030	13563-75020/0C010	13085-7J610	
		13085-84G00	
13561-0C010	13566-75010	13085-85G00	
13561-0C020	13566-23010/1	13085-99B00	
13561-0D010	13566-0J010	13085-AX000	
13561-0M010	13566-23020	13085-BX000	
13561-13020	13566-23030	13085-ED000/1HC2A	
13561-21010	13566-40020/0Q010	13085-MA70A	
13561-21020	13566-40020/40030	13085-N8400/1	
13561-21040	13566-B1020	13085-U6000	
13561-22010	13566-BZ010	13085-W0400	
13561-22020		13085-1JB1A	
13561-25010	13591-40020/0Q010	13085-JG30A/JA00A	
13561-28010	13591-40040		
13561-31010/AD010	13591-B1020		
13561-33020/0N010	13591-BZ010		
13561-34010/33011	13591-23010/0J010		
13561-35010	13591-23020		
13561-35020	13591-23030		
13561-37020/37050			
13561-38010			
13561-0T010/0T080			

## GUIDE (DAMPER)

<b>MAZDA</b>	<b>ISUZU</b>	<b>MITSUBISHI</b>	<b>SUZUKI</b>	<b>DAIHATSU</b>
<b>0222-12-610</b>	<b>8-94201-961-1</b>	<b>1140A026</b>	<b>12771-77E00</b>	<b>13566-97401(-000)</b>
<b>0222-12-660A</b>	<b>8-94201-962-2</b>	<b>1140A041</b>	<b>12771-85FA0</b>	<b>13591-97401(-000)</b>
<b>0290-12-610</b>	<b>8-94213-819-0</b>	<b>MD002930</b>	<b>12772-77E00/1</b>	
<b>0290-12-610C</b>	<b>8-94213-832-0</b>	<b>MD002935</b>	<b>12772-85FA0</b>	
<b>0290-12-660</b>	<b>8-97945-069-0</b>	<b>MD021111</b>	<b>12774-85FA1</b>	
<b>0324-12-660</b>	<b>8-97945-070-0</b>	<b>MD021114</b>	<b>12775-85FA0</b>	
<b>0370-12-610B</b>		<b>MD021156</b>	<b>12811-77E00</b>	
<b>0398-12-610</b>		<b>MD021231</b>		
<b>AM01-12-661</b>		<b>MD021232</b>		
<b>AM01-15-611</b>		<b>MD153644</b>		
<b>AM15-11-731</b>		<b>ME190013</b>		
<b>AM15-11-751</b>		<b>ME190016</b>		
<b>AM15-11-9Y8</b>		<b>ME191029</b>		
<b>E301-12-610</b>		<b>ME200423</b>		
<b>E301-12-660</b>		<b>ME200476</b>		
<b>G601-11-751A</b>		<b>ME203093</b>		
<b>G601-11-771</b>		<b>ME203096</b>		
<b>G601-12-611A</b>		<b>ME203833</b>		
<b>G601-12-671</b>		<b>ME204247</b>		
<b>G613-11-731A</b>				
<b>ZJ01-12-610</b>				
<b>ZY08-12-670/670A</b>				

## GEAR & PULLEY

TOYOTA	TOYOTA	NISSAN	NISSAN
13065-45010	13523-0D010/20	13021-01M00	13024-03G00
13519-28010	13523-13030	13021-03G00	13024-0M200
13519-37010/0T010	13523-15010	13021-21000/U0100	13024-18001/H8500
13521-0C010	13523-21020/0M010	13021-21000/U8010	13024-30000/U8000/1
13521-06010	13523-22010	13021-30000/01W00	13024-30800/01W00
13521-0D010/20/30	13523-22020/0M020	13021-31U00/1	13024-40F00
13521-13020	13523-23040	13021-32200/73600/1	13024-41B00
13521-13040	13523-23050/0J010	13021-40F01/53J00	13024-4M510
13521-15010	13523-28030	13021-41B00	13024-53F00
13521-22010	13523-31030/AD010	13021-4M501	13024-53Y00/1/2
13521-22020	13523-33010	13021-53Y00/1/2/10	13024-5M000
13521-23010	13523-33021	13021-5M000	13024-6N211/AU420
13521-23020	13523-35010	13021-77A00	13024-77A00
13521-23030/40/B1020	13523-35020	13021-7J601	13024-78200/1
13521-28010/30	13523-38010/1	13021-AX000	13024-7J600
13521-31010	13523-41011/43010	13021-BX000	13024-85G00
13521-31011/31020	13523-41011/45010	13021-D0100	13024-9E000
13521-31060/AD010	13523-66020	13021-ED000/EE50A	13024-AX000
13521-33010	13523-75010	13021-H1000/18002	13024-BX000
13521-33020	13523-75020	13021-H1000/H8900	13024-CJ00B
13521-35010	13523-75030/0C020	13021-6N200/6N20A	13024-EA000
13521-38010/1	13523-97401	13021-EA00A	13024-ED000/50A
13521-40020	13523-B1010/BZ060		13024-EE50B/ET000
13521-41011			13024-CK80A/CK80B
13521-60010	13528-33010		
13521-66020			
13521-75010	13530-31010/11/0P011		13077-0M200/0M300
13521-75020			13077-41B00/41B01
13521-97401	15163-28010/0T010		13077-53Y00/53Y01
13521-37010/11			13077-9E000/5V100
13521-0T030			
13521-37020/0T060			13095-DC000
			13095-MA70C
13522-33010			13143-2W203
13522-41011			13143-MA70A/LC30A
			15043-1KT0A/1A
			15043-3HD1A
			15043-9U50A
			15043-ED000

## GEAR & PULLEY

<b>MAZDA</b>	<b>MITSUBISHI</b>	<b>ISUZU</b>	<b>SUZUKI</b>	<b>DAIHATSU</b>
0222-11-316	MD000622	8-94109-590-1	12631-77E00	13521-97401(-000)
0222-12-425	MD000920	8-94200-972-1	12741-77E00	13523-97401(-000)
0249-11-316	MD002727/8	8-94200-973-0/1	12741-85FA0	
0249-12-425	MD002920/4920	8-94213-815-0	12742-85FA0	
0290-11-316	MD010622	8-94213-816-0	12745-77E00/1	
0305-11-325A	MD010920	8-97312-330-1		
0305-11-325B	MD016634	8-97312-331-0/1		
0305-12-425A/B	MD016860	9-12520-610-0		
0305-14-143/0222-14-143	MD020823/843	9-12521-605-0		
0305-14-143A	MD021170	9-12522-618-0		
0370-11-321/0324-11-321A	MD021172	9-12522-620-0		
0370-11-321A/3953-11-321	MD021180			
0370-11-321B	MD021181			
0370-11-323/0324-11-323A	MD021236/246			
0370-12-425/0324-12-425	ME200748			
0370-12-425A/3953-12-425	ME203099			
0370-14-181/0324-14-181	ME190341			
3953-11-321A/E303-11-323				
8057-12-425				
8569-11-323				
8682-12-425				
AM01-11-316				
AM01-12-425				
AM15-11-316				
AM15-11-9Y3				
E301-11-323				
E301-12-425				
E301-14-181				
E303-12-425				
G601-11-316				
G601-12-425				
G601-11-701				
ZJ01-11-316				
ZJ01-12-425				

# O.S.K. TIMING KIT

LA FABRICA "OSK LTD. JAPAN" RECOMIENDA REEMPLAZAR EL JUEGO COMPLETO DE PARTES PARA MAYOR DURACION Y RENDIMIENTO.

RECOMMEND TO REPLACE AS WHOLE **TIMING KIT** INSTEAD OF INDIVIDUAL COMPONENTS FOR LONG LIFE AND STABLE QUALITY CONDITION.



**ALL MADE IN JAPAN** 

TODAS LAS PARTES QUE CONTIENE ESTE JUEGO "O.S.K." ESTAN MARCADAS "JAPAN" PARA SU GARANTIA DE CALIDAD Y ORIGEN.

MARKED "O.S.K." ON THE KIT COMPONENTS TO GUARANTEE THE ORIGIN AND HIGH-QUALITY.

**HEAD OFFICE : 1-6-5 , HIRANOBABA ,  
HIRANO-KU , OSAKA , JAPAN  
TEL : 81 – 6 – 6791 – 7209  
FAX : 81 – 6 – 6793 – 6108  
URL : [www.timingkit.jp](http://www.timingkit.jp)  
E-MAIL : [hi@osk-parts.co.jp](mailto:hi@osk-parts.co.jp)**

**FACTORY : OKAYAMA (JAPAN)  
WAKAYAMA (JAPAN)**